

Index

A

- abort changes, 3-42
- Advanced Options, 3-36
- Advanced PIO Mode, 3-16
- AGP, 2-1
- Alert on LAN (AOL), 2-13, 2-14, 3-23
- audio controller, 3-21

B

- BIOS bottom command lines, 3-3
- BIOS level
 - advanced, 3-2
 - basic, 3-2
 - BIOS levels, 3-2
 - Level 1, 3-2
 - Level 2, 3-2
- BIOS main menu, 3-2
- BIOS version, 3-10
- Boot from LanDesk Service Agent, 3-28
- Boot Options, 3-26
- boot sequence, 3-26

C

- C8000h - DFFFFh Shadow, 3-39
- cache scheme, 3-38
- CD-ROM Drive DMA Mode, 3-16
- Celeron
 - installation, 4-28
- Configuration Table, 3-28
- connecting components, 1-4, 1-8
 - fax/modem, 1-11
 - keyboard, 1-4
 - monitor, 1-5
 - mouse, 1-6

- multimedia, 1-9
- printer, 1-7
- CPU
 - upgrade, 4-18
 - removing, 4-18

D

- Date and Time, 3-29
- DIMM
 - installation, 4-16
 - removal, 4-17
- Disk Drives, 3-11
- diskette drive configuration, 3-11
- display adapter, 3-27
- DMA Transfer Mode, 3-16
- drive control settings, 3-35
- drive cylinder, 3-14
- drive head, 3-15
- drive sector, 3-15
- drive size, 3-15
- drive type, 3-14

E

- ECP DMA, 3-21
- Enter setup, 3-2
- ESD, 4-1
- exit Setup, 3-43

F

- fast boot, 3-27
- floppy disk controller, 3-22
- floppy drive A, 3-6
- floppy drive B, 3-6

G

Graphics Aperture Size, 3-41

H

hard disk 32-bit access, 3-16

Hard Disk Block Mode, 3-15

hard disk drive configuration, 3-13

HDD size>504MB, 3-15

I

IDE 1

- master, 3-6

- slave, 3-7

IDE 2

- master, 3-7

- slave, 3-7

IDE configuration, 3-13

IDE controller, 3-22

IRQ sharing, 3-40

IRQ12, 3-22

ISA card installation, 4-12

J

jumper settings label, 4-3

L

L1 cache, 3-6, 3-37

L2 cache, 3-38

LanDesk, 3-28

LDCM, 2-12

loading default settings, 3-42

LS-120 configuration, 3-12

LSA, 2-14

M

magic packet, 2-13, 3-23

main board ID, 3-10

main board serial number, 3-10

Memory at 15MB-16MB Reserved For, 3-38

memory configuration, 4-14

Memory Parity Mode, 3-38

memory test, 3-28

Memory/Cache Options, 3-37

MMX, 2-1

modem ring indicator, 3-25

Modem Ring-In, 2-13

N

network connection, 1-10

NIC, 2-14

num lock, 3-27

O

Onboard Device Settings, 3-22

Onboard Peripherals, 3-17

P

Parallel Port, 3-8

- address, 3-20

- configuration, 3-20

- IRQ, 3-20

parallel port operation modes, 3-21

PCI card installation, 4-11

PCI IRQ, 3-39

PCI slots, 3-40

Pentium II

- installation, 4-21, 4-24

Plug and Play, 3-41

PME, 2-14

PnP, 3-41

PnP/PCI Options, 3-39

Post installation, 4-3

- power, 3-25
- Power Management, 3-24
- power management mode, 3-24
 - sleep mode, 3-25
 - system sleep timer, 3-25
- power management modes, 3-24
 - IDE hdd standby mode, 3-24
- Power On password, 3-34
- Preinstallation, 4-2
- preinstallation, 1-1
- processor, 3-5
- processor speed, 3-5
- Product Information, 3-9
- Product Name, 3-9
- PS/2 mouse, 3-8
- PXE, 2-14

R

- removing cover, 4-4
- replacing cover, 4-6
- resetting IRQ assignments, 3-41
- retention mechanism, 4-20
- RTC
 - Time, 3-30

S

- Serial Port 1, 3-8
 - address, 3-18
 - configuration, 3-18
 - IRQ, 3-18
- Serial Port 2, 3-8
 - address, 3-19
 - configuration, 3-19
 - IRQ, 3-19
- Setup password
 - bypassing, 3-33
 - changing, 3-32
 - removing, 3-32
 - setting, 3-31
- silent boot, 3-27
- SM BIOS version, 3-10

- special features, 2-1
- supported operating systems, 2-2
- system board
 - board layout, 2-4
- system disassembly, 4-7
- system features, 1-2
 - front panel, 1-2
 - rear panel, 1-3
- System Information, 3-4
- system power off, 1-13
- system power on, 1-13
- system reassembly, 4-9
- system reconfiguration, 4-17
- System Security Setup, 3-30
- system serial number, 3-9
- system total memory, 3-7

T

- TFTP, 2-14
- troubleshooting, 1-14
 - error messages, 1-15

U

- USB, 2-12
- USB controller, 3-23
- USB device installation, 1-12
- USB legacy mode, 3-23

V

- VGA palette snooping, 3-40
- video feature, 2-9
 - supported modes, 2-9

W

- Wake-on LAN, 2-13, 3-23
- wake-up event, 3-25
- Wireless Communication, 2-14

write-back, 3-38

write-through, 3-38

