

7A1647A

User's Manual Version 1.0

The information presented in this publication has been carefully prepared to ensure reliability ; however, no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

IBM, PC/AT, and PC/XT are trademarks of International Business Machines Corporation.

Athlon is a trademark of AMD Corporation

AWARD is a registered trademark of Phoenix Software Inc.

MS-DOS and WINDOWS NT are registered trademarks of Microsoft Corporation.

Trademarks and/or registered trademarks are the properties of their respective owners.

Table of Contents

Introduction

1. Motherboard Description

1.1 Feature	
1.1.1 Hardware	1-2
1.1.2 Software	1-4
1.1.3 Attachments	1-4
1.2 Motherboard Installation	
1.2.1 Motherboard Map	1-5
1.2.2 Motherboard Layout	1-6
1.3 Motherboard Connectors	
1.3.1 Front Panel Connector(JP20)	1-8
1.3.2 Floppy Disk Connector(FDD1)	1-9
1.3.3 Hard Disk Connectors(IDE1/IDE2)	1-9
1.3.4 ATX 20-pin Power Connector(PW1)	1-10
1.3.5 Infrared Connector(JP13)	1-10
1.4 Back Panel Connectors	
1.4.1 PS/2 Mouse/Keyboard CONN.	1-11
1.4.2 USB Connectors(USB1/USB2)	1-11
1.5 Serial and Parallel Interface ports	1-13
1.6 CPU Installation	
1.6.1 CPU Installation Product(Socket 462)	1-15
1.6.2 CPU Clock Frequency Setting(JP16)	1-16
1.6.3 CPU Ratio Selection(JP14)	1-17
1.7 Jumper Setting	
1.7.1 CPU Fan Connectors(FAN1/2)	1-18
1.7.2 Wake-On-Modem Header(WOM1)	1-19
1.7.3 Wake-On-LAN Header(WOL1)	1-19
1.7.4 AMR Code Select(JP3)	1-19
1.7.5 Keyboard Wake up Setting(JP1)	1-19
1.7.6 CMOS Function Select(JP17)	1-20
1.8 DDR SDRAM Installation	
1.8.1 DDR	1-21
1.8.2 How to install a DDR Module	1-21

Table of Contents

1.9 Audio Subsystem	
1.9.1 CD-Audio-in Connectors(JP4)	1-22
1.9.2 Telephone in Connector(JP2)	1-23
1.9.3 AUX Audio in Connector(JP7)	1-23
1.9.4 Video in Connector(JP6)	1-23

2. BIOS Setup

2.1 Main Menu	2-4
2.2 Standard CMOS Features	2-7
2.3 Advanced BIOS Features	2-10
2.4 Advanced Chipset Features	2-14
2.5 Integrated Peripherals	2-17
2.6 Power Management Setup	2-22
2.7 PnP/PCI Configurations	2-26
2.8 PC Health Status	2-30
2.9 Frequency/Voltage Control	2-32
2.10 Load Fail-Safe Defaults	2-33
2.11 Load Optimized Defaults	2-34
2.12 Set User Password	2-35
2.13 Save & Exit Setup	2-37
2.14 Exit Without Saving	2-38

3. Driver Installation

3.1 Auto-run Menu	3-1
3.2 Installing IDE Driver	3-2
3.3 Installing Audio Driver	3-3
3.4 Installing AGP Driver	3-4
3.5 Installing Hardware Monitoring Utility	3-5