

6A815EPD

User's Manual Version 1.3

The information presented in this publication has been made carefully for reliability; however, no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

IBM, PC/AT, and PC/XT are trademarks of International Business Machines Corporation.

Socket370 is a trademark of Intel Corporation

AWARD is a registered trademark of Phoenix Software Inc.

MS-DOS and WINDOWS NT are registered trademarks of Microsoft Corporation.

Trademarks and/or registered trademarks are the properties of their respective owners.

Table of Contents

Introduction

1. Motherboard Description

1.1 Features	
1.1.1 Hardware	1-2
1.1.2 Software	1-5
1.1.3 Attachments	1-5
1.2 Motherboard Installation	
1.2.1 Layout of Motherboard	1-6
1.3 Motherboard Connectors	
1.3.1 Front Panel Connectors(PANEL1)	1-8
1.3.2 Floppy Disk Connector(FDC1)	1-9
1.3.3 Hard Disk Connectors(IDE1/IDE2&IDE3/ID4)	1-9
1.3.4 ATX 20-pin Power Connector(PW1)	1-10
1.3.5 Infrared Connector(IR/CIR)	1-10
1.4 Back Panel Connectors	
1.4.1 PS/2 Mouse/Keyboard CONN.	1-11
1.4.2 USB Connectors	1-11
1.5 Serial and Parallel Interface ports	1-13
1.6 CPU Installation	
1.6.1 CPU Installation Product(Socket 370)	1-15
1.6.2 CPU Clock Frequency Setting(JP14)	1-16
1.7 Jumper Setting	
1.7.1 CPU Fan Connector(FAN1/2/3)	1-17
1.7.2 Wake-On-Modem Header(WOM1)	1-18
1.7.3 Wake-On-LAN Header(WOL1)	1-18
1.7.4 Watch DOG(JP1)	1-18
1.7.5 CMOS Function Setting(JP9)	1-18
1.7.6 KB/MS PWR-ON(JP1)	1-19
1.7.7 Wake on 2nd USB Port(JP4)	1-19
1.7.8 SBLINK Setting(JP5)	1-19
1.7.9 Timeout Reboot(JP7)	1-19
1.7.10 CPU Safe Mode(JP8)	1-20
1.7.11 Chassic Connector(CHASSIC1)	1-20

Table of Contents

1.7.12 IrDA Connectors(IR/CIR)	1-20
1.7.13 SBLINK Connector	1-21
1.8 DRAM Installation	
1.8.1 DIMM	1-22
1.8.2 How to install a DIMM Module	1-22
1.9 Audio Subsystem	
1.9.1 CD-Audio-IN Connectors(CD1/CD2)(option)	1-23
1.9.2 System Speaker(JP10)	1-24
1.10 Smart Panel Onboard Connector (option)	
1.10.1 Port 80 Debug Function(ERR2)	1-26
1.10.2 Second BIOS Connector(JP6)	1-26
1.10.3 GPIO Port Connector(JP3)	1-26

2. BIOS Setup

2.1 Main Menu	2-4
2.2 Standard CMOS Features	2-7
2.3 Advanced BIOS Features	2-10
2.4 Advanced Chipset Features	2-14
2.5 Integrated Peripherals	2-17
2.6 Power Management Setup	2-23
2.7 PnP/PCI Configurations	2-28
2.8 PC Health Status	2-32
2.9 Frequency/Voltage Control	2-34
2.10 Load Fail-Safe Defaults	2-35
2.11 Load Optimized Defaults	2-36
2.12 Set Supervisor/user Password	2-37
2.13 Save & Exit Setup	2-39
2.14 Exit Without Saving	2-40

3. Driver Installation

3.1 Auto-run Menu	3-1
3.2 Installing Intelinf Driver	3-2
3.3 Installing Ultra ATA Driver	3-3
3.4 Installing Hardware Monitoring Utility	3-4
3.5 Installing Onboard IDE RAID Driver	3-5
3.6 Installing Win2000 RAID Driver	3-7