

6M810E2

User's Manual Version 1.0

The information presented in this publication has been carefully prepared to ensure reliability ; however, no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

IBM, PC/AT, and PC/XT are trademarks of International Business Machines Corporation.

Socket370 is a trademark of Intel Corporation

AWARD is a registered trademark of Phoenix Software Inc.

MS-DOS and WINDOWS NT are registered trademarks of Microsoft Corporation.

Trademarks and/or registered trademarks are the properties of their respective owners.

Table of Contents

Introduction

1. Motherboard Description

1.1 Features	
1.1.1 Hardware	2
1.1.2 Software	5
1.1.3 Attachments	5
1.2 Motherboard Installation	
1.2.1 Layout of Motherboard	6
1.3 Motherboard Connectors	
1.3.1 Front Panel Connectors(PANEL1)	8
1.3.2 Floppy Disk Connector(FDD1)	9
1.3.3 Hard Disk Connectors(IDE1/IDE2)	9
1.3.4 ATX 20-pin Power Connector(PW1)	10
1.3.5 Infrared Connector(IR1)	10
1.4 Back Panel Connectors	
1.4.1 PS/2 Mouse/Keyboard CONN.	11
1.4.2 USB Connectors	11
1.4.3 VGA Interface Connector(VGA)	11
1.5 Serial and Parallel Interface ports	13
1.6 CPU Installation	
1.6.1 CPU Installation Product(Socket 370)	15
1.6.2 CPU Frequency Selection(JCLK1)	16
1.7 Jumper Setting	
1.7.1 CPU Fan Connector(FAN1/2/3)	17
1.7.2 Wake-On-Modem Header(WOM1)	18
1.7.3 Wake-On-LAN Header(WOL1)	18
1.7.4 CMOS Function Selection(CMOS1)	18
1.7.5 SPEAKER Selection(WATCH1)	19
1.7.6 AC97 Serial data out(STRAP1)	19

Table of Contents

1.8 DRAM Installation	
1.8.1 DIMM	20
1.8.2 How to install a DIMM Module	20
1.9 Audio Subsystem	
1.9.1 CD-Audio-IN Connectors(CDIN1/CDIN2)	21
1.9.2 Telephone in Connector(TAD1)	22
1.9.3 AUX Audio in Connector(AUX1)	22

2. BIOS Setup

2.1 Main Menu	26
2.2 Standard CMOS Features	29
2.3 Advanced BIOS Features	32
2.4 Advanced Chipset Features	36
2.5 Integrated Peripherals	39
2.6 Power Management Setup	45
2.7 PnP/PCI Configurations	50
2.8 PC Health Status	54
2.9 Frequency/Voltage Control	56
2.10 Load Fail-Safe Defaults	57
2.11 Load Optimized Defaults	58
2.12 Set Supervisor/user Password	59
2.13 Save & Exit Setup	61
2.14 Exit Without Saving	62