

630TM

User's Manual Version 1.0

The information presented in this publication has been made carefully for reliability; however, no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

IBM, PC/AT, and PC/XT are trademarks of International Business Machines Corporation.
Socket370 is a trademark of Intel Corporation
AWARD is a registered trademark of Phoenix Software Inc.
MS-DOS and WINDOWS NT are registered trademarks of Microsoft Corporation.

Trademarks and/or registered trademarks are the properties of their respective owners.

Table of Contents

Introduction

1. Motherboard Description

1.1 Introduction	1-1
1.2 Package Contents	1-1
1.3 Features	1-2
1.4 630TM Motherboard Layout	1-4
1.5 CPU Installation	1-7
1.6 DIMM DRAM Installation	1-8
1.7 Connectors & Jumper Setting	
1.7.1 Back Panel Connectors	
1.7.1.1 PS/2 Mouse/Keyboard CONN.	1-9
1.7.1.2 USB Port Connector (USB1)	1-9
1.7.1.3 Serial Interface ports	1-10
1.7.1.4 VGA Interface Connector(VGA)	1-10
1.7.1.5 Parallel Interface port	1-10
1.7.1.6 Joystick / Midi Connector	1-10
1.7.1.7 Audio Port Connector	1-10
1.7.2 ATX 4-pin/20-pin Power Connector: ATX	1-11
1.7.3 Floppy Disk Connector: FDC	1-11
1.7.4 Hard Disk Connectors: IDE1/IDE2	1-12
1.7.5 CPU Fan Connectors: SYSFAN/CPUFAN	1-12
1.7.6 CD-Audio-IN Connector: CDIN1/CDIN2	1-13
1.7.7 AUX in Connector: AUX_IN	1-13
1.7.8 Wake-On-LAN Header: WOL	1-14
1.7.9 Front USB2 Connector: USB2	1-15
1.7.10 Front Panel Connector: JP8	1-15
1.7.11 CMOS Function Selection: JP6	1-17
1.7.12 CPU & SDRAM Clock Setting: JP2/JP10/JP11	1-18
1.7.13 Keyboard Power on Function Setting: JP9	1-19
1.7.14 IrDA Connector: IR	1-19

Table of Contents

2. BIOS Setup

2.1 Main Menu	2-4
2.2 Standard CMOS Features	2-7
2.3 Advanced BIOS Features	2-10
2.4 Advanced Chipset Features	2-14
2.5 Integrated Peripherals	2-18
2.6 Power Management Setup	2-24
2.7 PnP/PCI Configurations	2-28
2.8 PC Health Status	2-31
2.9 Frequency/Voltage Control	2-33
2.10 Load Fail-Safe Defaults	2-34
2.11 Load Optimized Defaults	2-35
2.12 Set Supervisor/user Password	2-36
2.13 Save & Exit Setup	2-38
2.14 Exit Without Saving	2-39

3. Driver Installation

3.1 Auto-run Menu	3-1
3.2 Installing SiS AGP Driver	3-2
3.3 Installing AudioDriver	3-4
3.4 Installing Onboard LAN Driver	3-5

a. Appendix