

693A/AP

User's Manual Version 1.1

The information presented in this publication has been made carefully for reliability; however, no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

IBM, PC/AT, and PC/XT are trademarks of International Business Machines Corporation.

Pentium is a trademark of Intel Corporation

AWARD is a registered trademark of Phoenix Software Inc.

MS-DOS and WINDOWS NT are registered trademarks of Microsoft Corporation.

Trademarks and/or registered trademarks are the properties of their respective owners.

Table of Contents

Introduction

1. Motherboard Description

1.1 Features	
1.1.1 Hardware	2
1.1.2 Software	4
1.1.3 Attachments	4
1.2 Motherboard Installation	
1.2.1 Layout of Motherboard	5
1.3 Motherboard Connectors	
1.3.1 Front Panel Connectors(PANEL1)	7
1.3.2 Floppy Disk Connector(FDD1)	8
1.3.3 Hard Disk Connectors(IDE1/IDE2)	8
1.3.4 ATX 20-pin Power Connector(PW1)	9
1.3.5 Infrared Connector(J6)	9
1.4 Back Panel Connectors	
1.4.1 MS1 Mouse/Keyboard CONN.	10
1.4.2 USB Connectors	10
1.5 Serial and Parallel Interface ports	12
1.6 CPU Installation	
1.6.1 CPU Installation Product(Socket 370)	14
1.6.2 CPU Clock Setting(JCK1~JCK2,JFREQ1)	15
1.7 Jumper Setting	
1.7.1 CPU Fan Connector(FAN1/2/3)	17
1.7.2 CMOS Function Selection(JBAT1)	18
1.8 DRAM Installation	
1.8.1 DIMM	19
1.8.2 How to install a DIMM Module	19
1.9 Audio Subsystem	
1.9.1 CD-Audio-IN Connector(J5)	20

Table of Contents

2. BIOS Setup	
2.1 Main Menu	24
2.2 Standard CMOS Setup	27
2.3 BIOS Features Setup	30
2.4 Chipset Features Setup	34
2.5 Integrated Peripherals	38
2.6 Power Management Setup	42
2.7 PnP/PCI Configurations	47
2.8 Load Setup Defaults	50
2.9 Set Supervisor/user Password	51
2.10 IDE HDD Auto Detection	52
2.11 Save & Exit Setup	53
2.12 Exit Without Saving	54