

6V8633A

User's Manual Version 1.0

The information presented in this publication has been carefully prepared to ensure reliability ; however, no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

IBM, PC/AT, and PC/XT are trademarks of International Business Machines Corporation.

Socket370 is a trademark of Intel Corporation

AWARD is a registered trademark of Phoenix Software Inc.

MS-DOS and WINDOWS NT are registered trademarks of Microsoft Corporation.

Trademarks and/or registered trademarks are the properties of their respective owners.

Table of Contents

Introduction

1. Motherboard Description

1.1 Features	
1.1.1 Hardware	1-2
1.1.2 Software	1-4
1.1.3 Attachments	1-4
1.2 Motherboard Installation	
1.2.1 Motherboard Map	1-5
1.2.2 Motherboard Layout	1-6
1.3 Motherboard Connectors	
1.3.1 Front Panel Connectors(PANEL)	1-8
1.3.2 Floppy Disk Connector(FDD)	1-9
1.3.3 Hard Disk Connectors(IDE1/IDE2)	1-9
1.3.4 ATX 20-pin Power Connector(ATX)	1-10
1.3.5 Infrared Connector(IR)	1-10
1.4 Back Panel Connectors	
1.4.1 PS/2 Mouse/Keyboard CONN.	1-11
1.4.2 USB Connectors	1-11
1.5 Serial and Parallel Interface ports	1-13
1.6 CPU Installation	
1.6.1 CPU Installation Product(Socket 370)	1-15
1.6.2 CPU Frequency Setting(JCLK)	1-16
1.7 Jumper Setting	
1.7.1 CPU Fan Connector(FAN1/2/3)	1-17
1.7.2 Wake-On-Modem Header(WOM)	1-18
1.7.3 Wake-On-LAN Header(WOL)	1-18
1.7.4 CODEC Selection(J2)	1-18
1.7.5 CMOS Function Select(CMOS)	1-18
1.7.6 Classic Intrusion Connector(JCASE)	1-19
1.7.7 IrDA Connector(IR)	1-19

Table of Contents

1.8 DDR SDRAM Installation	
1.8.1 DDR	1-20
1.8.2 How to install a DDR Module	1-20
1.9 Audio Subsystem	
1.9.1 CD-Audio-IN Connectors(CDIN1/CDIN2)	1-21
1.10 Smart Panel Onboard Connector (option)	
1.10.1 Port 80 Debug Function(ERR)	1-23
1.10.2 Second BIOS Connector(BIOS)	1-23
1.10.3 Smart Panel Display Function(JGP)	1-23

2. BIOS Setup

2.1 Main Menu	2-4
2.2 Standard CMOS Features	2-7
2.3 Advanced BIOS Features	2-10
2.4 Advanced Chipset Features	2-14
2.5 Integrated Peripherals	2-18
2.6 Power Management Setup	2-24
2.7 PnP/PCI Configurations	2-29
2.8 PC Health Status	2-33
2.9 Frequency/Voltage Control	2-35
2.10 Load Fail-Safe Defaults	2-36
2.11 Load Optimized Defaults	2-37
2.12 Set Supervisor/user Password	2-38
2.13 Save & Exit Setup	2-40
2.14 Exit Without Saving	2-41

3. Driver Installation

3.1 Auto-run Menu	3-1
3.2 Installing VIA 4 in 1 Driver	3-2
3.3 Installing Audio Driver	3-3
3.4 Installing Hardware Monitoring Utility	3-5