

6VIA83

User's Manual Version 1.0

The information presented in this publication has been made carefully for reliability; however, no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

IBM, PC/AT, and PC/XT are trademarks of International Business Machines Corporation.

Pentium is a trademark of Intel Corporation

AWARD is a registered trademark of Phoenix Software Inc.

MS-DOS and WINDOWS NT are registered trademarks of Microsoft Corporation.

Trademarks and/or registered trademarks are the properties of their respective owners.

Table of Contents

Chapter 1	Introduction	1
	How this manual is organized	1
	Package checklist	2
Chapter 2	Features	3
	Features of the mainboard	3
	The mainboard layout	6
Chapter 3	Installation	7
	System Installation Setups	9
	Static Electricity Precaution	9
	Jumper Settings	10
	System Memory (DIMM modules)	12
	DIMM Memory Installation	13
	CPU Installation	15
	Clearance Requirements	16
	Fan Exhaust	16
	External Connectors	17
Chapter4	Audio Installation.....	26

Note:

If there is any change in the content please refer to our website.Regarding the BIOS setting & Driver installation,refer the web site please.([www. acorp.com.tw](http://www.acorp.com.tw))