

Addendum

Note 1:

Make sure that “JP6” is in Normal Operation Status (Short pins 1-2) before you boot up your system.

Note 2:

We want to inform you that the SPDIF header on the board is an optional item. If you get the board that does not have the SPDIF header that means your board does not provide the SPDIF function.

Note 3:

Please notice that the correct jumper setting for JP1 is as follows:

JP1: Keyboard power on jumper

Use this 3-pin jumper to enable keyboard power on with hot keys or password.

Function	Jumper Cap
Enable keyboard power on	Short pins 2-3
Disable keyboard power on	Short pins 1-2

