

Contents

Chapter 1: Introduction	1
Welcome	1
About the Manual	2
Checklist.....	3
Standard Items	3
Recommendations	3
Features	4
 Chapter 2: Installation	 7
Quick Installation Table	7
Quick Jumper Setting Reference	8
Before You Begin	10
Static Electricity	10
Choosing a Case	10
How to Set Jumpers	11
Preparing the Mainboard.....	12
Mainboard Guide	12
I/O Ports Side View.....	14
Check the Jumper Settings	15
Install the Mainboard in the Case.....	17
Connecting Power, Chassis Fans, and Switches and Indicators.....	19
Install Other Hardware	21
Install the Processor	21
Installing a Socket-370 Processor	22
Install the Memory Modules.....	24
Install a Hard Disk Drive and CD-ROM	25
Installing a Floppy Diskette Drive	27
Using the Expansion Slots.....	29
Add-in Card Options	30
Install Options and Extension Brackets	31
Make the External Connections	36
External Connector Color Coding.....	37

Chapter 3: Setup	38
About the Setup Utility	38
Starting the Setup Utility	38
How to Flash a New BIOS	40
Standard CMOS Features Option	41
Advanced BIOS Features Setup Option	43
Advanced Chipset Features Option	46
Integrated Peripherals Option	49
Power Management Setup Option	51
PNP/PCI Configuration Option	54
PCI Health Status Option	55
Frequency Control Option	56
Load Fail-Safe Defaults Option	57
Load Optimized Defaults Option	57
Set Password	57
Save And Exit Setup Option	58
Exit Without Saving Option	58
 Chapter 4: Software	 59
About the Software	59
Folders for this Mainboard	59
Running the Support CD-ROM	61
Utility Folder Installation Notes	61
CMI8X38 Folder Installation Notes	62
Audio Software	62
Modem Driver and Software	63
Peripheral Folder Installation Notes	63
SiS_IDE Folder Installation Notes	64
Mainboard (P6STP-FL) Installation Notes	64
 Appendix 1: Quick Jumper Setting Reference	 65