













**CPU External Clock (Bus) Frequency: JK1, JK2, JK3, JK4**

The table below shows the jumper settings for the different CPU speed configurations. Set the corresponding External Clock and CPU Clock Rate jumpers according to the CPU speed of the system by following the tables below.

	JK1	JK2	JK3	JK4
<b>25 MHz</b> SX-25 DX-25 SX2-50 DX2-50 DX4-75				
<b>33 MHz (Default)</b> SX-33 DX-33 SX2-66 DX4-100 X5-133				
<b>40 MHz</b> DX2-80 DX4-120				
<b>50 MHz</b> DX-50	