

Table of Contents

Chapter 1 Overview

Main Features	2
Advanced Features	3
Package Checklist	5
Mainboard Layout (with onboard COM1 and COM2 ports)	6
Mainboard Layout (with onboard USB port)	7
This User's Manual	8
Something Interesting	8
The BIOS Setup Utility	9
IRQ Functionality	9
DMA Channels of ISA Cards	10
Enhanced IDE	10
Infrared Connections	10
Highly Convenient Integrated I/O Connectors	11

Chapter 2 Installation Procedures

Mainboard Layout (with onboard COM1 and COM2 ports)	14
Mainboard Layout (with onboard USB port)	15
1). Set System Jumpers	16
Jumpers	16
Clear Password: CPW	17
Flash EPROM Type Selection: EP1, EP2	17
CPU to SRAM Data Transaction Mode Selection: SRAM1	18
VGA Selection: VGA1	18
2). Install System RAM Modules	19
DRAM Memory	19
DRAM Module Configuration	20
Install SIMMs	21
Remove SIMMs	22
Install DIMMs	22
Remove DIMMs	23
Cache Memory	23
Option 1: 512KB Cache SRAM	23
Option 2: 256KB Cache SRAM	24
Option 3: 512KB Cache SRAM	24
Option 4: 1MB Cache SRAM	25

3). Install the Central Processing Unit (CPU)	25
Select Frequency and Voltage	27
CPU to Bus Frequency Ratio: FREQ1, FREQ2, FREQ3	27
CPU External Clock (Bus) Frequency: CLK1, CLK2, CLK3 ..	28
Intel Pentium CPUs	29
Frequency.....	29
Voltage.....	30
AMD-K5/K6 CPUs.....	31
Frequency.....	31
Voltage.....	32
Cyrix 6x86/6x86MX / IBM 6x86/6x86MX CPUs	33
Frequency.....	33
Voltage.....	34
4). Install Expansion Cards	35
Assigning IRQs for Expansion Cards	37
Assigning DMA Channels for ISA Cards	37
5). Connector Cables and Power Supply	38
Connectors	38
Floppy Diskette Drive Connector (34-pin block): FLOPPY	38
Infrared Connector: IR	39
Serial Port Connectors (Two 9-pin Male): COM1, COM2	39
Serial Port and Serial Connector: COM1, COM2_E	40
Standard Power Connector: POWER.....	40
IDE HDD Device Connector: PRIMARY, SECONDARY.....	41
Universal Serial Bus Port: USB (with onboard USB port)	42
Universal Serial Bus Connector: USB	42
PS/2 Keyboard Connector (6-pin Female): PS2_KB	43
PS/2 Mouse Connector (6-pin Female): PS2_MS	43
Remote Power Supply Connector: RPW_CON1	44
CPU Fan Connector: CHASIS FAN, CPU_FAN.....	45
Front Panel Block Connector: F_PNL	46
LAN System Wakeup Connector: LAN_WAKE	47
System Chassis Open Alarm Connector: CHASIS	48
VGA Feature Connector: FEATURE.....	48
VGA Connector: VGA	49
Parallel Printer Connector (25-pin Female): PRINTER.....	49
Power Connection Procedures	50
Powering Off the Computer.....	50

Chapter 3 Setting BIOS Feature

Main CMOS Setup.....	52
Load Defaults	52
Standard CMOS Setup	52
Auto Detection of Hard Disks on Bootup	54
BIOS Features Setup.....	55
Chipset Features Setup.....	58
Power Management Setup.....	60
PNP and PCI Setup	63
Load BIOS Defaults	64
Load Setup Defaults.....	65
Integrated Peripherals	65
Supervisor Password and User Password.....	68
IDE HDD Auto Detection.....	69
Save & Exit Setup.....	70
Exit Without Saving.....	70

— This Page Intentionally Left Blank —