

Table of Contents

Chapter 1 Overview

Main Features	1
---------------------	---

Chapter 2 Installation Procedures

Mainboard Layout	4
1). Set System Jumpers	5
CPW	5
EP1	5
SRAM	5
2). Install System Memory	6
DRAM and SDRAM	6
RAM Module Configuration	7
Install SIMMs	8
Remove SIMMs	8
Install DIMMs	9
Remove DIMMs	9
Cache Memory	10
3). Install the CPU	11
CPU External Clock (Bus) Frequency: CLK1, CLK2, CLK3 ..	12
CPU to Bus Frequency Ratio: FREQ1, FREQ2, FREQ3	12
Intel Pentium CPUs	13
Frequency	13
Voltage	14
AMD-K5/K6 CPUs	15
Frequency	15
Voltage	16
Cyril 6x86 CPUs	17
Frequency	17
Voltage	18
IBM 6x86 CPUs	19
Frequency	19
Voltage	20
4). Connector Cables and Power Supply	21
AT Keyboard Connector: AT_KB	21

Serial Port Connectors: COM1, COM2	21
CPU Fan Connector: FAN.....	22
Floppy Diskette Drive Connector: FLOPPY	22
Infrared Connector: IR	23
PS/2 Mouse Connector: MS_CON	23
Front Panel Block Connector: F_PNL	24
Standard Power Connector: POWER.....	25
IDE HDD Device Connectors: PRIMARY, SECONDARY	25
Printer Connector: PRINTER	26
Universal Serial Bus Connectors: USB1, USB2	26

Chapter 3 Award BIOS Setup

CMOS Setup Utility.....	27
Standard CMOS Setup	28
Hard Disk Configurations.....	28
BIOS Features Setup.....	30
Chipset Features Setup.....	33
Power Management Setup.....	37
PCI Configuration Setup.....	40
PnP Configuration Setup	42
Load BIOS Defaults	43
Load Setup Defaults.....	43
Supervisor/User Password.....	43
IDE HDD Auto Detection.....	44
Save and Exit Setup	45
Exit without Saving.....	45

Appendix A BIOS Update Instruction

Flash Process	47
---------------------	----