

Chapter 1 Overview

Package Checklist	1-2
The KA11 Mainboard	1-3
Main Features	1-4
ACPI Ready	1-6
FIC Unique Innovation for Users (NOVUS) -	
Enhanced Mainboard Features and System Support	1-6

Chapter 2 Installation Procedures

Quick Reference	2-2
1). Set System Jumper	2-9
Mainboard Layout	2-10
Clear CMOS: SW1-5	2-12
Clear Password: SW1-6	2-12
Enabling Keyboard Wake-Up Feature: KB_WAKE	2-13
2). Install RAM Modules	2-13
RAM Module Configuration	2-13
Install and Remove DIMMs	2-14
3). Install the CPU	2-14
CPU Frequency Selection	2-17
CPU Voltage Selection	2-17
4). Install Expansion Cards	2-18
5). Connect Devices	2-20
Floppy Diskette Drive Connector: Floppy	2-20
IDE HDD Device Connectors:	
Primary, Secondary	2-21
ATX Power Connector: POWER	2-21
CPU Fan Connector: CPU_FAN	2-22
System Case Fan Connector: CHS_FAN1, CHS_FAN2	2-22
Wake-On-LAN Connector: WOL	2-23
System Chassis Intrusion Alarm Connector: CHASSIS	2-23
Infrared Connector: IR	2-24
CD Audio-Out Connector: CD_IN1, CD_IN2	2-24
Power Fan Connector: PWR_FAN	2-25
Front Panel Block Connector: FPNL	2-26
PS/2 Keyboard and Mouse Connector: KB, MS	2-27

Universal Serial Bus Connectors: USB0, USB1, USB2 (optional)	2-27
Printer Connector: LPT	2-28
Serial Port Connectors: COM1, COM2	2-28
GAME/MIDI Connector: GAME	2-29
Audio I/O Jacks: LINE_OUT, LINE_IN, MIC_IN	2-29

Chapter 3 BIOS Setup

CMOS Setup Utility	3-1
Standard CMOS Setup	3-2
Hard Disk Configurations	3-2
Software Turbo Speed	3-3
BIOS Features Setup	3-3
Chipset Features Setup	3-6
Power Management Setup	3-10
PNP/PCI Configuration	3-14
Load BIOS Defaults	3-16
Load Setup Defaults	3-16
Integrated Peripherals	3-17
Supervisor/User Password	3-22
IDE HDD Auto Detection	3-22
Save and Exit Setup	3-22
Exit without Saving	3-22

Chapter 4 FAQs

General FAQs	4-1
BIOS FAQs	4-2
Windows 98/98 SE FAQs	4-5
Windows 95 FAQs	4-6