

Table of Contents

Chapter 1 Overview

| | |
|--|---|
| Package Checklist | 2 |
| The VA-503 Mainboard..... | 3 |
| Main Features | 4 |
| Advanced Features | 6 |
| PC '97 Compliant | 7 |
| Infrared Connection | 7 |
| Universal Serial Bus (USB) Functionality | 8 |

Chapter 2 Installation Procedures

| | |
|---|----|
| Mainboard Layout | 10 |
| 1). Set System Jumpers | 11 |
| Jumpers | 11 |
| Clear Password: CPW | 11 |
| Flash ROM Type Selection: EP1, EP2..... | 12 |
| Power Supply Type Selection: PWR..... | 13 |
| CPU to SRAM Data Transacting Mode Selection: SRAM | 13 |
| 2). Install System RAM Modules..... | 13 |
| RAM Module Configuration | 13 |
| Install SIMMs..... | 16 |
| Remove SIMMs..... | 16 |
| Install DIMMs | 17 |
| Remove DIMMs | 17 |
| Cache Memory..... | 18 |
| 3). Install the CPU..... | 19 |
| CPU External Clock (BUS) Frequency: CLK1, CLK2, CLK3.. | 20 |
| CPU Internal Freq. to Bus Clock Ratio: | |
| FREQ1, FREQ2, FREQ3 | 20 |
| Intel Pentium MMX CPUs | 21 |
| Frequency | 21 |
| Voltage | 21 |
| AMD-K6 CPUs | 22 |
| Frequency | 22 |
| Voltage | 23 |

VA-503 Mainboard Manual

| | |
|--|----|
| Cyrix 6x86L/6x86MX CPUs..... | 24 |
| Frequency | 24 |
| Voltage | 25 |
| IBM 6x86L/6x86MX CPUs | 26 |
| Frequency | 26 |
| Voltage | 27 |
| 4). Install Expansion Cards | 28 |
| 5). Connect Cables and Power Supply..... | 29 |
| Keyboard Connector: AT_KB | 29 |
| Serial Port Connectors: COM1, COM2 | 29 |
| Universal Serial Bus Connectors: USB..... | 29 |
| CPU Fan Connector: CPU_FAN..... | 30 |
| System Case Fan Connector: CHAS_FAN..... | 30 |
| Infrared Connector: IR..... | 30 |
| Floppy Diskette Drive Connector: FDD..... | 31 |
| Remote Power Connector: CN5 | 31 |
| EICA CPU Fan Connector: EICA | 31 |
| PS/2 Mouse Connector: MS_CON | 32 |
| Printer Connector: LPT | 32 |
| IDE HDD Device Connectors: PRIMARY, SECONDARY..... | 32 |
| AT Power Supply Connector: POWER..... | 33 |
| ATX Power Supply Connector: ATX_PWR | 33 |
| Remote Wake-Up Connector: RWU..... | 33 |
| Front Panel Block Connector: F_PNL | 34 |
| Chapter 3 BIOS Setup | |
| CMOS Setup Utility | 35 |
| Standard CMOS Setup..... | 36 |
| Hard Disk Configurations..... | 36 |
| Software Turbo Speed | 37 |
| BIOS Features Setup..... | 38 |
| Chipset Features Setup | 41 |
| Power Management Setup..... | 44 |
| PNP/PCI Configuration Setup | 48 |
| Load BIOS Defaults..... | 50 |

Installation Procedures

| | |
|-------------------------------|----|
| Load Setup Defaults..... | 50 |
| Integrated Peripherals..... | 50 |
| Supervisor/User Password..... | 54 |
| IDE HDD Auto Detection | 55 |
| Save and Exit Setup | 56 |
| Exit without Saving..... | 56 |

Appendix A Software Utilities

| | |
|--|----|
| Bus Master IDE Driver..... | 57 |
| VIA INF Update Software..... | 57 |
| AGP VxD Support Utility | 57 |
| Anti-Virus Tool (optional)..... | 57 |
| Desktop Management Interface (DMI) Software..... | 58 |
| BIOS Flash Software | 58 |

This Page Intentionally Left Blank