

## **Table of Contents**

### **Chapter 1 Overview**

Package Checklist .....	1
The VB-601 Motherboard .....	2
Main Features .....	3
ACPI Ready .....	4

### **Chapter 2 Installation Procedures**

Motherboard Layout .....	6
1). Set System Jumpers/Switches .....	7
Clear CMOS: SW1-5 .....	7
Clear Password: SW1-6 .....	7
Flash ROM Type Selection: EP1, EP2 .....	8
Keyboard and Mouse Power-On Feature: KB_PWN .....	8
2). Install RAM Modules .....	9
RAM Module Configuration .....	9
Install and Remove DIMMs .....	10
3). Install the CPU .....	11
I). Install with Foldable Retention Mechanism Assembly .....	11
II). Install with Non-Foldable Retention Mechanism Assembly .....	13
CPU Internal Frequency: SW-1, SW-2, SW-3, SW-4 .....	16
4). Install Expansion Cards .....	17
5). Connect Devices .....	19
Connect to Internal Devices .....	19
Floppy Diskette Drive Connector: FLOPPY .....	19
ATX Power Connector: POWER .....	19
IDE HDD Device Connectors: PRIMARY, SECONDARY .....	20
CPU Fan Connector: FAN1 .....	21
Wake-On-LAN Connector: WOL .....	21
PCI Audio Card Connector: SB_LINK .....	22
Connect to System Case .....	23
Front Panel Block Connector: F_PNL .....	23
Suspend Switch Connector: SP_SW .....	24
System Case Fan Connector: FAN2 .....	25
Connect to External Devices .....	26
Serial Port Connectors: COM1, COM2 .....	26
Printer Connector: LPT .....	26
PS/2 Keyboard and Mouse Connector: KB/MS .....	27
Infrared Connector: IR .....	27

Universal Serial Bus Connectors: USB0, USB1, J1 .....	28
---	----

### Chapter 3 BIOS Setup

CMOS Setup Utility.....	29
Standard CMOS Setup .....	30
Hard Disk Configurations.....	30
Software Turbo Speed .....	31
BIOS Features Setup.....	31
Chipset Features Setup.....	33
Power Management Setup .....	36
PNP/PCI Configuration .....	40
Load BIOS Defaults .....	41
Load Setup Defaults.....	41
Integrated Peripherals .....	42
Supervisor/User Password.....	46
IDE HDD Auto Detection.....	47
Save and Exit Setup .....	48
Exit without Saving.....	48

### Chapter 4 Software Utilities

Starting Installation.....	49
LANDesk Client Manager (manufacturing option).....	49
LDCM 3.21 Specification Overview .....	49
Two Options of LDCM Setup.....	50
Desktop Management Interface (DMI).....	51
Starting DMI.....	51
Editing DMI.....	51
Adding DMI.....	52
Loading DMI .....	52
Saving DMI .....	53
Setup ACPI Under Windows 98 .....	53
Bus Master IDE Driver .....	54
Installation.....	54
Patch for Chipset.....	54
Installation.....	54
BIOS Flash Software.....	55
Downloading BIOS File .....	55

Table of Contents

---

Upgrading BIOS File.....	55
Loading New BIOS Defaults .....	56
Anti-Virus Tool.....	56
Hardware Requirements.....	56
Technical Notes .....	56

**This Page Left Blank for Note**