

PENTIUM
TX 400

☒ **Notice**

The information in this document is subject to change in order to improve reliability, design, or function without prior notice and does not represent a commitment on the part of this company. In no event will we be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or the possibility of such damages.

All trademarks are the property of their respective owners.

If you need any further information, please visit our web-site:
“www.qdigrp.com”.

Jumper Quick Setting 1,2
-----------------------------	------------------

Introduction

<i>Overview</i>	<i>..... 1-1</i>
<i>Key Features</i>	<i>..... 1-1</i>

Jumper Configuration

<i>System Clock Selection</i>	<i>..... 2-1</i>
<i>Clock Multiplier Selection</i>	<i>..... 2-2</i>
<i>CPU Frequency Selection</i>	<i>..... 2-2</i>
<i>CPU Type & Voltage Selection</i>	<i>..... 2-8</i>
<i>Clear CMOS</i>	<i>..... 2-9</i>
<i>Memory Configuration</i>	<i>..... 2-9</i>

Connector Configuration

<i>Power Connector</i>	<i>..... 3-1</i>
<i>Standby Power Connector</i>	<i>..... 3-1</i>
<i>Power Switch</i>	<i>..... 3-2</i>
<i>Keyboard Connector</i>	<i>..... 3-2</i>
<i>Hard Disk LED Connector</i>	<i>..... 3-2</i>
<i>Keylock Connector</i>	<i>..... 3-3</i>
<i>Speaker Connector</i>	<i>..... 3-3</i>
<i>IrDA Connector</i>	<i>..... 3-3</i>
<i>Turbo LED Connector</i>	<i>..... 3-3</i>
<i>USB1/USB2 Connector</i>	<i>..... 3-4</i>
<i>FAN Connector</i>	<i>..... 3-4</i>
<i>Hardware Green</i>	<i>..... 3-4</i>
<i>Reset Switch</i>	<i>..... 3-4</i>
<i>PS2 Mouse</i>	<i>..... 3-5</i>
<i>I/O Port Description</i>	<i>..... 3-5</i>
<i>Illustration of Connectors on board.....</i>	<i>3-6</i>

AWARD BIOS Description

<i>Entering BIOS Setup</i>	4-1
<i>Standard CMOS Setup</i>	4-2
<i>BIOS Features Setup</i>	4-4
<i>Chipset Features Setup</i>	4-7
<i>Power Management Setup</i>	4-9
<i>PNP/PCI Configuration</i>	4-12
<i>Load Setup Defaults</i>	4-13
<i>Integrated Peripherals</i>	4-14
<i>Password Setting</i>	4-15
<i>IDE HDD Auto Detection</i>	4-16
<i>Power-On Boot</i>	4-18

Appendix

<i>Appendix A. BIOS Upgrade Diskette</i>	5-1
<i>Appendix B. AMD-K5 CPU MARK</i>	5-2
<i>Appendix C. AMD-K6 CPU MARK</i>	5-3
<i>Appendix D. Cyrix 6x86 CPU MARK</i>	5-4
<i>Appendix E. Cyrix 6x86MX CPU MARK</i>	5-5

Jumper Quick Setting

CPU Installation

JS1, JS2 and JS3 are used for System Clock settings.

JC1 and JC2 are used for CPU multiple clock settings.

(Please refer to pages 2-1 ~ 2-7 for detailed information)

	<i>CPU Frequency</i>	<i>JC1</i>	<i>JC2</i>	<i>JS1</i>	<i>JS2</i>	<i>JS3</i>
Intel Pentium (P54C & P55C)	75MHz	2-3	2-3	1-2	1-2	1-2
	90 MHz	2-3	2-3	1-2	2-3	2-3
	100 MHz	2-3	2-3	2-3	2-3	2-3
	120 MHz	1-2	2-3	1-2	2-3	2-3
	133 MHz	1-2	2-3	2-3	2-3	2-3
	150 MHz	1-2	1-2	1-2	2-3	2-3
	166 MHz	1-2	1-2	2-3	2-3	2-3
	180 MHz	2-3	1-2	1-2	2-3	2-3
	200 MHz	2-3	1-2	2-3	2-3	2-3
	233 MHz	2-3	2-3	2-3	2-3	2-3
Cyrix 6x86	P120+(100 MHz)	1-2	2-3	1-2	1-2	1-2
	P133+(110 MHz)	1-2	2-3	1-2	1-2	2-3
	P150+(120 MHz)	1-2	2-3	1-2	2-3	2-3
	P166+(133 MHz)	1-2	2-3	2-3	2-3	2-3
	P200+(150 MHz)	1-2	2-3	2-3	1-2	2-3
Cyrix 6x86MX	PR166(150 MHz)	1-2	1-2	1-2	2-3	2-3
	PR200(150 MHz)	1-2	2-3	2-3	1-2	2-3
	PR200(166 MHz)	1-2	1-2	2-3	2-3	2-3
	PR233(188MHz)	1-2	1-2	2-3	1-2	2-3
	PR233(200MHz)	2-3	1-2	2-3	2-3	2-3
AMD K5	PR75(75 MHz)	2-3	2-3	1-2	1-2	1-2
	PR90,PR120(90 MHz)	2-3	2-3	1-2	2-3	2-3
	PR100,PR133(100 MHz)	2-3	2-3	2-3	2-3	2-3
	PR166	1-2	1-2	2-3	2-3	2-3
	PR200	2-3	1-2	2-3	2-3	2-3
AMD K6	166(166 MHz)	1-2	1-2	2-3	2-3	2-3
	200(200 MHz)	2-3	1-2	2-3	2-3	2-3
	233(233 MHz)	2-3	2-3	2-3	2-3	2-3

Select CPU Type & Voltage

JV, JV2, JV3, JV4 and JV5 are used to select your CPU voltage.

(Please refer to pages 2-8 for details.)

	Single Voltage CPU	Dual	Voltage	CPU
--	--------------------	------	---------	-----

