

Table of Contents

Chapter 1: Introduction

| | |
|------------------------|---|
| Welcome..... | 1 |
| About the Manual | 1 |
| Checklist..... | 2 |
| Features..... | 2 |

Chapter 2: Installation

| | |
|--|---|
| Before You Begin | 4 |
| Mainboard Guide.. | 5 |
| Preparing the Mainboard | 6 |
| Install the Mainboard in the System Case | 9 |

Chapter 3: Setup

| | |
|--|----|
| About the Setup Utility..... | 12 |
| Standard CMOS Setup Option.. | 14 |
| BIOS Feature Setup Option..... | 15 |
| Chipset Features Option. | 17 |
| Power Management Setup Option | 19 |
| PNP/PCI Configuration Option.. | 21 |
| Load BIOS Defaults Option | 22 |
| Load Setup Defaults Option..... | 23 |
| Integrated Peripherals Option... | 23 |
| Supervisor Password and User Password | 25 |
| IDE HDD Auto Detection Option | 26 |
| Save and Exit Setup Option..... | 26 |
| Exit Without Saving Option | 26 |

Chapter 4: Software

| | |
|-------------------------|----|
| About the Software..... | 27 |
|-------------------------|----|

| | |
|--|-----------|
| Appendix 1: Quick Jumper Setting Reference... | 29 |
|--|-----------|