

Chapter 4: Software

About the Software

The support software for this mainboard is supplied on either a CD-ROM disk, or a floppy diskette, depending on the configuration of the mainboard. Some mainboard configurations do not need all the software described in this chapter.

- ◆ Bus master IDE drivers
- ◆ LANDesk Client Management Software (LDCM) (Optional)
- ◆ Flash BIOS utilities
- ◆ Desktop Management Interface (DMI) utility (Optional)
- ◆ Windows 95 Patch program
- ◆ Winbond system monitor utility (Optional)

General Installation Guide

1. Log on to the directory on the CD-ROM that contains the software.
2. Look for a text file named README.TXT or something similar. Use a text editor to display and read the file. This file may have updated information about the latest versions of the software.
3. Look for a program named SETUP.EXE or INSTALL.EXE and run the program.
4. Follow the directions on the screen to install the software.

Bus master IDE drivers

The Bus master IDE drivers are located in the directory \IDEDRV\TRIONES.

LANDesk Software

The LANDesk software is located in the directories \LDCM with sub-directories for \LDCM\CLIENT and \LDCM\ADMIN. You can use the ALF editor to modify the customized client and Administrator.

When you first setup LDCM, the program will install a version of Internet Explorer (IE) if your system does not already have a version of IE later than 3.02. You must restart the LDCM installation after the installation of IE is completed.

Client Manager uses a simple setup program to install the administrator functionality. Setup installs the LANDesk Client Manager console, DMI Control Panel, and the Notification Monitor.

To run Setup on Windows NT

1. Log in as Administrator or equivalent.
2. Run SETUP.EXE from the Client Manager CD-ROM and follow the instructions on your monitor.

To run Setup on Windows 95

1. Run SETUP.EXE from the Client Manager CD-ROM and follow the instructions on your monitor.

Flash BIOS Utility

The flash BIOS utility can be used to erase the BIOS from the flash BIOS EEPROM on the motherboard, and install an updated version of the BIOS. There are two Flash BIOS utilities on the CD-ROM. One utility is located in \FLASH\ECS, and the other utility is located in \FLASH\AWARD.

DMI Utility

The DMI utility allows system integrators and administrators to make changes to the Desktop Management Interface. It is located in \DMI.

PIIX-4 Windows Patch Program

Most versions of Windows 95 cannot recognize the USB ports and power management routines on Pentium-II motherboards. This patch program named WINP2X4.EXE solves this problem. It is located in the directory \WINPATCH.

System Monitor Utility

The system monitor utility lets you monitor the critical system temperatures and voltages. You must have the optional sensor chip W83781D installed on your mainboard in order to use this utility.

Other Software Questions

Question

How can I install a PCI bridge and support for USB ports on this mainboard?

Answer

Find the file UPG.EXE on the CD or diskettes that ship with your mainboard. Run the file and then restart your system.