

613DF

USER'S MANUAL

Flex ATX Mainboard

For Socket 370 Processor

NO. G03-613DFR1A

Release date: OCT 2000

Trademark:

- * Pentium is registered trademark and MMX is a trademark of Intel Corporation, the other names and brands are the property of their respective owners
- * Specifications and Information contained in this documentation are furnished for information use only, and are subject to change at any time without notice, and should not be construed as a commitment by manufacturer.

TABLE OF CONTENT

USER'S NOTICE	1
MANUAL REVISION INFORMATION	2
THERMAL SOLUTIONS	2
CHAPTER 1 INTRODUCTION OF 613DF MOTHERBOARD	
1-1 FEATURE OF MOTHERBOARD.....	3
1-2 SPECIFICATION	4
1-3 PERFORMANCE LIST	5
1-4 LAYOUT DIAGRAM & JUMPER SETTING	6
CHAPTER 2 HARDWARE INSTALLATION	
2-1 HARDWARE INSTALLATION STEPS.....	8
2-2 CHECKING MOTHERBOARD'S JUMPER SETTING	8
2-3 INSTALL CPU	9
2-3-1 ABOUT PENTIUM® & CELERON™ 370-PIN CPU	9
2-3-2 SETTING CPU BUS CLOCK & MEMORY CLOCK JUMPER	10
2-3-3 INSTALL CPU	11
2-3-4 OVERCLOCK RUNNING	11
2-4 INSTALL MEMORY	14
2-5 EXPANSION CARD	14
2-5-1 PROCEDURE FOR EXPANSION CARD INSTALLATION	14
2-5-2 ASSIGNING IRQ FOR EXPANSION CARD	14
2-5-3 INTERRUPT REQUEST TABLE FOR THIS MOTHERBOARD.....	15
2-5-4 TV OUT SLOT.....	15
2-6 CONNECTORS, HEADERS	16
2-6-1 CONNECTORS	16
2-6-2 HEADERS	19
2-7 STARTING UP YOUR COMPUTER.....	22
CHAPTER 3 INTRODUCING BIOS	
3-1 ENTERING SETUP.....	23
3-2 GETTING HELP	24
3-3 THE MAIN MENU	24
3-4 STANDARD CMOS FEATURES	26
3-5 ADVANCED BIOS FEATURES	27
3-6 ADVANCED CHIPSET FEATURES	30
3-7 INTEGRATED PERIPHERALS.....	31
3-7-1 ONBOARD IDE FUNCTION.....	32
3-7-2 ONBOARD PCI DEVICE.....	33
3-7-3 WINBOND SUPERIO DEVICE	34

3-8	POWER MANAGEMENT SETUP.....	35
3-8-1	RELOAD TIMER EVENTS	37
3-9	PNP/PCI CONFIGURATION SETUP	38
3-10	PC HEALTH STATUS.....	39
3-11	FREQUENCY/VOLTAGE CONTROL	40
3-12	LOAD STANDARD/OPTIMIZED DEFAULTS	40
3-13	SET SUPERVISOR/USER PASSWORD.....	41

CHAPTER 4 DRIVER & FREE PROGRAM INSTALLATION

	MAGIC INSTALL SUPPORTS WINDOWS 95/98/98SE/NT4.0/2000	42
4-1	INF INSTALL INTEL 810E CHIPSET SYSTEM DRIVER	43
4-2	IDE INSTALL ULTRA ATA33 OR ULTRA ATA 66 DRIVER	44
4-3	VGA INSTALL ON-BOARD VGA DRIVER	45
	A. For WINDOWS 95/98/98SE/NT4.0	45
	B. For WINDOWS 2000	45
4-4	PC-HEALTH INSTALLS PC HEALTH MONITOR IIII SOFTWARE FOR HARDWARE MONITORING DEVICE	47
4-5	AC97 SOUND DRIVER AND THE PROGRAM INSTALL FOR EDITING/PLAYBACK.....	48
4-6	LAN (RTL8139C) INSTALL 10/100M PCI FAST ETHERNET DRIVER	49
4-7	PC-CILLIN INSTALL PC-CILLI N98 ANTI-VIRUS PROGRAM.....	50
4-8	HOW TO UTILIZE ALSRACK EDITING & PLAYBACK UTILITY... 51	
4-9	HOW TO UTILIZE PC-HEALTH	52
4-10	HOW TO DISABLE ON-BOARD SOUND	52
4-11	HOW TO UPDATE BIOS.....	52

USER'S NOTICE

COPYRIGHT OF THIS MANUAL BELONGS TO **THE MANUFACTURER**. NO PART OF THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT MAY BE REPRODUCED, TRANSMITTED OR TRANSLATED INTO ANY LANGUAGE IN ANY FORM OR BY ANY MEANS WITHOUT WRITTEN PERMISSION OF **THE MANUFACTURER**.

THIS MANUAL CONTAINS ALL INFORMATION REQUIRED TO USE 613DF MOTHERBOARD AND WE DO ASSURE THIS MANUAL MEETS USER'S REQUIREMENT BUT WILL CHANGE, CORRECT ANY TIME WITHOUT NOTICE. **MANUFACTURER** PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, AND WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFIT, LOSS OF BUSINESS, LOSS OF USE OF DATA, INTERRUPTION OF BUSINESS AND THE LIKE).

PRODUCTS AND CORPORATE NAMES APPEARING IN THIS MANUAL MAY OR MAY NOT BE REGISTERED TRADEMARKS OR COPYRIGHTS OF THEIR RESPECTIVE COMPANIES, AND THEY ARE USED ONLY FOR IDENTIFICATION OR EXPLANATION AND TO THE OWNER'S BENEFIT, WITHOUT INTENT TO INFRINGE.

Manual Revision Information

Reversion	Revision History	Date
1.0	First Release	Oct 2000

Item Checklist

- 613DF
- Cable for IDE/Floppy
- CD for motherboard utilities
Cable for USB Port 3/4 (Option)
- Cable for COM2
- 613DF User's Manual

Intel® Processor Family

Thermal Solutions

As processor technology pushes to faster speeds and higher performance, thermal management becomes increasingly crucial when building computer systems. Maintaining the proper thermal environment is key to reliable, long-term system operation. The overall goal in providing the proper thermal environment is keeping the processor below its specified maximum case temperature. Heatsinks induce improved processor heat dissipation through increased surface area and concentrated airflow from attached fans. In addition, interface materials allow effective transfers of heat from the processor to the heatsink. For optimum heat transfer, Intel recommends the use of thermal grease and mounting clips to attach the heatsink to the processor.

When selecting a thermal solution for your system, please refer to the website below for collection of heatsinks evaluated and recommended by Intel for use with Intel processors.

Vendor list for heatsink and fan of **Pentium® !!! processor**, please visit :

<http://developer.intel.com/design/Pentiumiii/components/index.htm>

Vendor list for heatsink and fan of **Intel®Celeron™ processor**, please visit :

<http://developer.intel.com/design/celeron/components/index.htm>

Chapter 1

Introduction of 613DF Motherboard

1-1 Feature of motherboard

The 613DF motherboard is design for use Intel's new generation Pentium processors, which utilize the Socket 370 design and the memory size expandable to 512Mb (using 128Mb technology). This motherboard integrated VGA, Audio, LAN, PC Health Function with Flex ATX form factor to support total solution for today's computer market.

This motherboard use the newest Intel 810E chipset, whose 133MHz front side bus delivers a clear upgrade path to the future generation of 133MHz processors and PC-100/PC-133 SDRAM. The 613DF motherboard offers ULTRA DMA 66 (ATA 66) to provide speedier HDD throughout that boosts overall system performance.

A digital video out interface to support optional LCD panel or TV-OUT display Card. The 613DF also has an integrated AC'97 2.1 CODEC on board which is fully compatible with Sound Blaster Pro® that gives you the best sound quality and compatibility. 810E chipset includes integrated 3D Graphic Acceleration to provide a lower cost video display solution.

With 2 USB control as well as capability of expanding to 4 USB connectors, the 613DF meet future USB demand also this motherboard has built-in hardware monitor function. This will monitor and protect your computer.

This motherboard provides high performance & meets future specification demand. It is really wise choice for your computer.

1-2 Specification

Spec	Description
Design	* FLEX ATX form factor 4 layers PCB size: 23.0 x 19.0 cm
Chipset	* INTEL 810E Chipset
Clock Generator	* Winbond W83194R-We Support 66/100/133MHz system Bus Clock (CPU Bus Clock) Support 100 MHz system memory clock Support 33MHz PCI Bus clock
CPU Socket	* Support Pentium® III 500~1GHz processor * Support Celeron™ 300~733MHz processor * Support 66, 100 and 133MHz CPU Bus clock * Reserves support for future Intel Pentium® III processors
Memory Socket	* 168-pin DIMM socket x2 * PC-100/PC-133 SDRAM * Expandable to 512MB * Support 3.3V SDRAM DIMM
Expansion Slot & Headers	* 32-bit PCI slot x1 * AMR slot x1 * LCD/TV out expansion slot x1
Integrate VGA	* 3D graphic acceleration
Integrate IDE	* 2 channel of Bus Master IDE port supporting ULTRA DMA 33/66 mode devices
Audio	* AC'97 Digital Audio controller integrated * AC'97 Audio CODEC on board * Audio driver and utility included
LAN	* On Board RTL8139C PCI LAN controller * Support 10/100 Base T Transfer rate
PC Health	* Monitoring CPU/System Temperature, FAN Speed, and System Voltage
BIOS	* Award 4Mb Flash ROM
Multi I/O	* PS/2 keyboard and PS/2 mouse connectors * Floppy disk drive connector x1 * Parallel port x1 * Serial port x2 * USB connector x2 * USB headers x2 (connecting cable option) * Audio connector (Line-in, Line-out/MIC & Game Port)

1-3 Performance List

The following performance data list is the testing result of some popular benchmark testing programs. These data are just referred by users, and there is no responsibility for different testing data values gotten by users (the different Hardware & Software configuration will result in different benchmark testing results.)

CPU: Intel PIII® 866MHz FC-PGA package
DRAM: 128M SDRAM x2 (Hyundai GM 72V66841ET75)
VGA Expansion Card: Geforce 256 (1024x768 Hi-color) Driver V3.68
Hard Disk Driver: Quantum Fireball KX20A11
BIOS: Award Optimal default
OS: Win 98SE

Performance Test Report

	Copermine 866MHz	
3D Mark 99	1660	
3D Winbench 99 V1.2	301	
3D Winbench 2000	5.33	
Final Reality	5.25	
Winstone 99 V1.3	30.8	
Winstone 2000	31.9	
Winbench 99 :		
CPU Mark 99	69.7	
FPU Winmark 99	4610	
Business Disk Winmark99	4970	
Hi-end Disk Winmark99	17000	
Business Graphic Winmark	192	
Hi-end Graphic Winmark	734	
SYS Mark 2000 : SISMark 2000 Rating (Internet Content Creation / Office Productivity)		
Suites	158 (160/157)	
Offical	158 (159/157)	
SISOFT Sandra 2000 :		
CPU MIPS	2357	
FPU MFLOPS	1167	
CPU / Memory MB/S	202	
FPU / Memory MB/S	209	

Jumpers

Jumper	Name	Description	Page
JP16, JP17, J5	CPU & SDRAM Frequency Setting	3-pin Block	p.8
JP4	Keyboard Power ON Function Setting	3-pin Block	p.8
JP2	Clear Keyboard Power On Password Setting	3-pin Block	p.9
JP14	CMOS RAM Clear	3-pin Block	p.9

Connectors

Connector	Name	Description	Page
P2	ATX Power Connector	20-pin Block	p.16
KB&MS1	PS/2 Mouse & PS/2 Keyboard Connector	6-pin Female	p.16
USB/LAN	USB Port Connector LAN Connector	4-pin Connector RJ45 Connector	p.17
PRT1	Parallel Port Connector	25-pin Female	p.17
VGA	VGA Port Connector	15-pin Female	p.17
AGC	Audio/Game Connector	3 phone jack + 15-pin Connector	p.18
COM1	Serial Port COM1 Connector	9-pin Connector	p.18
FDC1	Floppy Driver Connector	34-pin Block	p.18
IDE1	Primary IDE Connector	40-pin Block	p.18
IDE2	Secondary IDE Connector	40-pin Block	p.19

Headers

Header	Name	Description	Page
COM2	COM2 Headers	10-pin Block	p.19
USB	Internal UBS Hub Headers	10-pin Block	p.19
IDELED	IDE activity LED	2-pin Block	p.20
TBLED	Turbo LED switch	2-pin Block	p.20
RESET	Reset switch lead	2-pin Block	p.20
KEYLOCK	Keyboard lock switch	2-pin Block	p.20
SPKEAR	Speaker connector	4-pin Block	p.20
PWR LED	Power LED	2-pin Block	p.20
PWR BTN	Power switch	2-pin Block	p.20
FAN1, FAN2, FAN3	FAN Speed Headers	3-pin Block	p.21
IR1	IR infrared module Headers	10-pin Block	p.21
J3, J4	CD Audio-In Headers	4-pin Block	p.21

Expansion Sockets

Socket/Slot	Name	Description	Page
ZIF Socket 370	CPU Socket	370-pin FC-PGA/PPGA CPU Socket	p.11
DIMM1, DIMM2	DIMM Module Socket	168-pin DIMM SDRAM Module Expansion Socket	p.13
PCI1	PCI Slot	32-bit PCI Local Bus Expansion slots	p.14
TV OUT	LCD/ TV-out Slot	Support LCD/TV-out card	p.15
AMR	AMR Slot	Support Audio Modem Riser Card	

Chapter 2

Hardware installation

2-1 Hardware installation Steps

Before using your computer, you had better complete the following steps:


1. Check motherboard setting
2. Install CPU
3. Install Memory
4. Install Expansion cards
5. Connect Ribbon cables, Panel wires, and power supply
6. Setup BIOS
7. Install software driver & utility

2-2 Checking Motherboard's Jumper Setting

1. CPU & SDRAM Clock setting (3-pin JP16, JP17, J5)


The motherboard's CPU & SDRAM memory clock adjusted through jumper JP16, JP17 & J5. Table as below:

CPU/SDRAM (MHz)	JP16	JP17	J5
66/100	2-3	2-3	2-3
100/100	1-2	2-3	2-3
133/100	1-2	1-2	1-2



2. Keyboard Power On Function setting (3-pin JP4)


This allows you to disable the keyboard power on function. Set the jumper to enabled or disabled if you wish to use your keyboard (by pressing < >) to power on your computer, this feature requires an ATX power supply that can supply at least 300mA on the +5VSB lead. The default is set on disable.



Keyboard Power On Function

3. Clear Keyboard Power On password setting (3-pin JP2)

You can set keyboard power on function password to assure computer security to setting password through BIOS SETUP, and you can clear keyboard power on password by JP2.




Clear Keyboard Power On Password Setting

4. CMOS RAM Clear (3-pin JP14)

A battery must be used to retain the motherboard configuration in CMOS RAM short 1-2 pins of JP14 to store the CMOS data.

Note: You can clear CMOS by shorting 2-3 pin, while the system is off. Then return to 1-2 pin position. Avoid clearing the CMOS while the system is on, it will damage the motherboard always unplug the power cord from the wall socket.



CMOS RAM Clear Setting

2-3 Install CPU

2-3-1 About Pentium® III & Celeron™ 370-pin CPU

This motherboard supports both Pentium III & Celeron 370 pins CPU.

The way to recognize the specification of CPU from the packing Pentium III 370 pins FC-PGA

On the surface of the CPU as shown on the right picture, under the word of “PENTIUM III” the code is:

RB 80526 P2 866 256

RB : FC-PGA packing

P2 : P2-133MHz front side bus frequency
PY-100MHz front side bus frequency

866 : CPU internal frequency, where here is 866MHz

256 : the size of L2 cache, where here is 256K



Celeron FC-PGA

On the surface of the CPU as shown on the right picture, under the word of “Celeron” the code is:

566/128/66/1.5V

566 : CPU internal frequency, where here is 566MHz

128 : the size of L2 cache, where here is 128K

66 : front side bus frequency, where here is 66MHz

1.5V : the voltage for the CPU



2-3-2 Setting CPU Bus Clock & Memory Clock Jumper

Setting the front side bus frequency and SDRAM frequency

The motherboard uses jumper JP16, JP17 and J5 for the front side bus frequency and SDRAM frequency setting as shown from the table below:

CPU/SDRAM (MHz)	J16	JP17	J5
66/100	2-3	2-3	2-3
100/100	1-2	2-3	2-3
133/100	1-2	1-2	1-2

Example: Using a Pentium® III 866 CPU with front side bus frequency of 133MHz and PC-133 SDRAM module, the setting of JP16, JP17 and J5 will be all 1-2. Will form CPU BUS CLOCK be 133MHz and SDRAM CLOCK be 100MHz.


For experience user looking for over clocking, please refer to sec 2-3-4

2-3-3 Install CPU

This motherboard provides a ZIF socket 370. The CPU that comes with the motherboard should have a cooling FAN attached to prevent overheating. If this is not the case, then purchase a correct cooling FAN before you turn on your system.

WARNING! Be sure that there is sufficient air circulation across the processor's heatsink and CPU cooling FAN is working correctly, otherwise it may cause the processor and motherboard overheat and damage, you may install an auxiliary cooling FAN, if necessary.

To install a CPU, first turn off your system and remove its cover. Locate the ZIF socket and open it by first pulling the level sideways away from the socket then upward to a 90-degree angle. Insert the CPU with the correct orientation as shown below. The notched corner should point toward the end of the level. Because the CPU has a corner pin for two of the four corners, the CPU will only fit in the orientation as shown.



When you put the CPU into the ZIF socket. No forces require to insert of the CPU, then press the level to locate position slightly without any extra force.

2-3-4 Over clock Running

WARNING! This section is for experienced motherboard installer only. Over clocking can result in system instability or even shortening life of the processor.

After setting the Jumper JP16, JP17 and J5 you can choose over clock running by BIOS CMOS SETUP UTILITY. When you entered CMOS SETUP UTILITY, choose "Frequency/Voltage control" you will see the screen as below then.

1. You can choose the situation you want to try.

JP16	JP17	J5	CPU Bus Clock	SDRAM Clock
2-3	2-3	2-3	66	100

CMOS Setup Utility - Copyright (C) 1984-2000 Award Software
Frequency/Voltage/Control

Auto Detect DIMM/PCI Clk	Enabled	Item Help												
Spread Spectrum	Disabled													
CPU/SDRAM Clock	F6-F7	Menu Level >												
CPU Clock Ratio														
<table border="1"> <tr> <td colspan="2">CPU/SDRAM Clock</td> </tr> <tr> <td>Default</td> <td>[]</td> </tr> <tr> <td>66 /100 Mhz.....</td> <td>[]</td> </tr> <tr> <td>75 /112 Mhz.....</td> <td>[]</td> </tr> <tr> <td>83 /124 Mhz.....</td> <td>[]</td> </tr> <tr> <td colspan="2">↑↓:Move ENTER:Accept ESC:Abort</td> </tr> </table>		CPU/SDRAM Clock		Default	[]	66 /100 Mhz.....	[]	75 /112 Mhz.....	[]	83 /124 Mhz.....	[]	↑↓:Move ENTER:Accept ESC:Abort		
CPU/SDRAM Clock														
Default	[]													
66 /100 Mhz.....	[]													
75 /112 Mhz.....	[]													
83 /124 Mhz.....	[]													
↑↓:Move ENTER:Accept ESC:Abort														
↑↓→←:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults														

2.

JP16	JP17	J5	CPU Bus Clock	SDRAM Clock
1-2	2-3	2-3	100	100


CMOS Setup Utility - Copyright (C) 1984-2000 Award Software
 Frequency/Voltage/Control

Auto Detect DIMM/PCI Clk	Enabled	Item Help												
Spread Spectrum	Disabled													
CPU/SDRAM Clock	F6-F7	Menu Level >												
CPU Clock Ratio														
<table border="1"> <tr> <td colspan="2">CPU/SDRAM Clock</td> </tr> <tr> <td>Default</td> <td>[]</td> </tr> <tr> <td>95 / 95 Mhz.....</td> <td>[]</td> </tr> <tr> <td>117/117 Mhz.....</td> <td>[]</td> </tr> <tr> <td>124/124 Mhz.....</td> <td>[]</td> </tr> <tr> <td colspan="2">↑↓:Move ENTER:Accept ESC:Abort</td> </tr> </table>		CPU/SDRAM Clock		Default	[]	95 / 95 Mhz.....	[]	117/117 Mhz.....	[]	124/124 Mhz.....	[]	↑↓:Move ENTER:Accept ESC:Abort		
CPU/SDRAM Clock														
Default	[]													
95 / 95 Mhz.....	[]													
117/117 Mhz.....	[]													
124/124 Mhz.....	[]													
↑↓:Move ENTER:Accept ESC:Abort														
↑↓→←:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults														

3.

JP16	JP17	J5	CPU Bus Clock	SDRAM Clock
1-2	1-2	1-2	133	100

CMOS Setup Utility - Copyright (C) 1984-2000 Award Software
 Frequency/Voltage/Control



NOTE! Our engineer has over clock running and tested for a few hours. Again we don't suggest user running over clock.

2-4 Install Memory

This motherboard provides **two** 168-pin DUAL INLINE MEMORY MODULES (DIMM) sites for memory expansion available from minimum memory size over 32MB to maximum memory size of 512MB SDRAM.

Valid Memory Configurations

DIMM1	DIMM2	System Accept or Not	Total Memory
			Min. ~ Max.
DS/SS		Accept	32MB~256MB
	DS/SS	Accept	32MB~256MB
DS/SS	DS/SS	Accept	32MB~512MB

DS : Double Sided DIMM SS : Single Sided DIMM

NOTE! Make sure the total installed memory does not exceeds 512MB, otherwise the system may hang during startup.

Generally, installing SDRAM modules to your motherboard is very easy, you can refer to figure 2-4 to see what a 168-Pin PC100 & PC133 SDRAM module looks like.





Figure 2-4

NOTE! When you install DIMM module fully into the DIMM socket the eject tab should be locked into the DIMM module very firmly and fit into its indentation on both sides.

WARNING! For the SDRAM CLOCK is set at 133MHz, use only PC133-compliant DIMMs. When this motherboard operate at 133Mhz, most system will not even boot if non-compliant modules are used because of the strict timing issues, if your DIMM are not PC133-compliant, set the SDRAM clock to 100MHz to ensure system stability.

2-5 Expansion Cards

WARNING! Turn off your power when adding or removing expansion cards or other system components. Failure to do so may cause severe damage to both your motherboard and expansion cards.

2-5-1 Procedure For Expansion Card Installation

1. Read the documentation for your expansion card and make any necessary hardware or software setting for your expansion card such as jumpers.
2. Remove your computer's cover and the bracket plate on the slot you intend to use.
3. Align the card's connectors and press firmly.
4. Secure the card on the slot with the screen you remove above.
5. Replace the computer system's cover.
6. Set up the BIOS if necessary.
7. Install the necessary software driver for your expansion card.

2-5-2 Assigning IRQs For Expansion Card

Some expansion cards need an IRQ to operate. Generally, an IRQ must exclusively assign to one use. In a standard design, there are 16 IRQs available but most of them are already in use.

Standard Interrupt Assignments

IRQ	Priority	Standard function
0	1	System Timer
1	2	Keyboard Controller
2	N/A	Programmable Interrupt
3 *	11	Communications Port (COM2)
4 *	12	Communications Port (COM1)
5 *	13	Sound Card (sometimes LPT2)
6	14	Floppy Disk Controller
7 *	15	Printer Port (LPT1)
8	3	System CMOS/Real Time Clock
9 *	4	ACPI Mode when enabled
10 *	5	IRQ Holder for PCI Steering
11 *	6	IRQ Holder for PCI Steering
12 *	7	PS/2 Compatible Mouse Port
13	8	Numeric Data Processor
14 *	9	Primary IDE Channel
15 *	10	Secondary IDE Channel

* These IRQs are usually available for ISA or PCI devices.

2-5-3 Interrupt Request Table For This Motherboard


Interrupt request are shared as shown the table below:

	INT A	INT B	INT C	INT D
PCI slot 1	Shared	—	—	—
Onboard LAN		Shared		
Onboard VGA	—	—	—	—
AC97/MC97	—	Shared	—	—
Onboard USB 0	—	—	—	Shared
Onboard USB 1	—	—	—	Shared

IMPORTANT! If using PCI cards on shared slots, make sure that the drivers support “Shared IRQ” or that the cards don’t need IRQ assignments. Conflicts will arise between the two PCI groups that will make the system unstable or cards inoperable.

2-5-4 TV OUT Slot

This Slot require an option LCD/TV-out card. Installing the LCD/ TV-out card you can connect to LCD Monitor or TV. By this card can let you have the same screen in both VGA monitor and LCD monitor or TV and VGA monitor.




2-6 Connectors, Headers

2-6-1 Connectors


(1) Power Connector (20-pin block) : P2

ATX Power Supply connector. This is a new defined 20-pins connector that usually comes with ATX case. The ATX Power Supply allows to use soft power on momentary switch that connect from the front panel switch to 2-pins Power On jumper pole on the motherboard. When the power switch on the back of the ATX power supply turned on, the full power will not come into the system board until the front panel switch is momentarily pressed. Press this switch again will turn off the power to the system board.




(2) PS/2 Mouse & PS/2 Keyboard Connector: KB&MS1

If you are using a PS/2 mouse, you must purchase an optional PS/2 mouse set which connects to the 5-pins block and mounts to an open slot on your computer's case.




(3) USB Port connector: USB

The connectors are 4-pins connector that connect USB devices to the system board.




(4) LAN Connector: LAN




(5) Parallel Port Connector (25-pin female): PRT1

Parallel Port connector is a 25-pin D-Subminiature Receptacle connector. The On-board Parallel Port can be disabled through the BIOS SETUP. Please refer to Chapter 3 "INTEGRATED PERIPHERALS SETUP" section for more detail information.




(6) VGA Connector (15-pin female): VGA



(7) **Audio and Game Connector : AGC**


This Connector are 3 phone Jack for LINE-OUT, LINE-IN, MIC and a 15-pin D-Subminiature Receptacle Connector for joystick/MIDI Device.

- Line-out :** Audio output to speaker
- Line-in :** Audio input to sound chip
- MIC :** Microphone Connector
- Game/MIDI :** For joystick or MIDI Device




(8) **Serial Port COM1: COM1**

COM1 is the 9-pin D-Subminiature mail connector. The On-board serial port can be disabled through BIOS SETUP. Please refer to Chapter 3 “INTEGRATED PERIPHERALS SETUP” section for more detail information.




(9) **Floppy drive Connector (34-pin block): FDC1**

This connector supports the provided floppy drive ribbon cable. After connecting the single plug end to motherboard, connect the two plugs at other end to the floppy drives.




(10) **Primary IDE Connector (40-pin block): IDE1**

This connector supports the provided IDE hard disk ribbon cable. After connecting the single plug end to motherboard, connect the two plugs at other end to your hard disk(s). If you install two hard disks, you must configure the second drive to Slave mode by setting its jumpers accordingly. Please refer to the documentation of your hard disk for the jumper settings.



(11) Secondary IDE Connector (40-pin block): IDE2

This connector connects to the next set of Master and Slave hard disks. Follow the same procedure described for the primary IDE connector. You may also configure two hard disks to be both Masters using one ribbon cable on the primary IDE connector and another ribbon cable on the secondary IDE connector.




- Two hard disks can be connected to each connector. The first HDD is referred to as the “Master” and the second HDD is referred to as the “Slave”.
- For performance issues, we strongly suggest you don’t install a CD-ROM or DVD-ROM drive on the same IDE channel as a hard disk. Otherwise, the system performance on this channel may drop.

2-6-2 Headers


(1) COM2 Headers (10-pin header) : COM2

This board has another serial port COM2, it come with cable providing serial port COM2.



(2) USB Port Headers (10-pin) : USB

These headers are used for connecting the additional USB port plug. By attaching an option USB cable, your can be provided with two additional USB plugs affixed to the back panel.



(3) IDE Activity LED: IDELED

This connector connects to the hard disk activity indicator light on the case.

(4) Turbo LED switch: TBLED

Since the motherboard's turbo function is always on. The turbo LED will remain constantly on while the system power is on. You may wish to connect the Power LED from the system case to this lead. See the figure below.

(5) Reset switch lead: RESET

This 2-pin connector connects to the case-mounted reset switch for rebooting your computer without having to turn off your power switch. This is a preferred method of rebooting in order to prolong the life of the system's power supply. See the figure below.

(6) Keyboard lock switch: KEYLOCK

This 2-pin connector connects to the case-mounted key switch for locking the keyboard for security purposes.

(7) Speaker connector: SPKEAR


This 4-pin connector connects to the case-mounted speaker. See the figure below.

(8) Power LED: PWR LED

The Power LED is light on while the system power is on. Connect the Power LED from the system case to this pin.

(9) Power switch: PWR BTN


This 2-pin connector connects to the case-mounted power switch to power ON/OFF the system.



System Case Connections


(10) FAN Speed Headers (3-pin) : FAN1, FAN2, FAN3

These connectors support cooling fans of 350mA (4.2 Watts) or less, depending on the fan manufacturer, the wire and plug may be different. The red wire should be positive, while the black should be ground. Connect the fan's plug to the board taking into consideration the polarity of connector.




(11) IR infrared module Headers (10-pin) : IR1

This connector supports the optional wireless transmitting and receiving infrared module. You must configure the setting through the BIOS setup to use the IR function.



(12) CD Audio-In Headers (4-pin) : J3, J4

J3 and J4 are the connectors for CD-Audio Input signal. Please connect it to CD-ROM CD-Audio output connector.



2-7 Starting Up Your Computer

1. After all connections are made, close your computer case cover.
2. Be sure all the switch are off, and check that the power supply input voltage is set to proper position, usually in-put voltage is 220V~240V or 110V~120V depending on your country's voltage used.
3. Connect the power supply cord into the power supply located on the back of your system case according to your system user's manual.
4. Turn on your peripheral as following order:
 - a. Your monitor.
 - b. Other external peripheral (Printer, Scanner, External Modem etc...)
 - c. Your system power. For ATX power supplies, you need to turn on the power supply and press the ATX power switch on the front side of the case.
5. The power LED on the front panel of the system case will light. The LED on the monitor may light up or switch between orange and green after the system is on. If it complies with green standards or if it is has a power standby feature. The system will then run power-on test. While the tests are running, the BIOS will alarm beeps or additional message will appear on the screen.

If you do not see any thing within 30 seconds from the time you turn on the power. The system may have failed on power-on test. Recheck your jumper settings and connections or call your retailer for assistance.

Beep	Meaning
One short beep when displaying logo	No error during POST
Long beeps in an endless loop	No DRAM install or detected
One long beep followed by three short beeps	Video card not found or video card memory bad
High frequency beeps when system is working	CPU overheated System running at a lower frequency

6. During power-on, press <Delete> key to enter BIOS setup. Follow the instructions in BIOS SETUP.
7. **Power off your computer:** You must first exit or shut down your operating system before switch off the power switch. For ATX power supply, you can press ATX power switching after exiting or shutting down your operating system. If you use Windows 9X, click “**Start**” button, click “**Shut down**” and then click “**Shut down the computer?**” The power supply should turn off after windows shut down.

Chapter 3

Introducing BIOS

The BIOS is a program located on a Flash Memory on the motherboard. This program is a bridge between motherboard and operating system. When you start the computer, the BIOS program gain control. The BIOS first operates an auto-diagnostic test called POST (power on self test) for all the necessary hardware, it detects the entire hardware device and configures the parameters of the hardware synchronization. Only when these tasks are completed done it gives up control of the computer to operating system (OS). Since the BIOS is the only channel for hardware and software to communicate, it is the key factor for system stability, and in ensuring that your system performance as its best.

In the BIOS Setup main menu of Figure 3-1, you can see several options. We will explain these options step by step in the following pages of this chapter, but let us first see a short description of the function keys you may use here:

- Press <Esc> to quit the BIOS Setup.
- Press ↑↓←→ (up, down, left, right) to choose, in the main menu, the option you want to confirm or to modify.
- Press <F10> when you have completed the setup of BIOS parameters to save these parameters and to exit the BIOS Setup menu.
- Press Page Up/Page Down or +/- keys when you want to modify the BIOS parameters for the active option.

3-1 Entering Setup

Power on the computer and by pressing immediately allows you to enter Setup.

If the message disappears before your respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the “RESET” button on the system case. You may also restart by simultaneously pressing <Ctrl>, <Alt> and <Delete> keys. If you do not press the keys at the correct time and the system does not boot, an error message will be displayed and you will again be asked to

Press <F1> to continue, <Ctrl-Alt-Esc> or to enter Setup

3-2 Getting Help

Main Menu

The on-line description of the highlighted setup function is displayed at the bottom of the screen.

Status Page Setup Menu/Option Page Setup Menu

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window, press <Esc>.

3-3 The Main Menu

Once you enter Award® BIOS CMOS Setup Utility, the Main Menu (Figure 3-1) will appear on the screen. The Main Menu allows you to select from fourteen setup functions and two exit choices. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.

CMOS Setup Utility - Copyright(C) 1984-2000 Award Software

Standard CMOS Features	Frequency/Voltage Control
Advanced BIOS Features	Load optimized Defaults
Advanced Chipset Features	Load Standard Defaults
Integrated Peripherals	Set Supervisor Password
Power Management Setup	Set User Password
PnP/PCI Configurations	Save & Exit Setup
PC Health Status	Exit Without Saving
Esc : Quit	: Select Item
F10 : Save & Exit Setup	
Time, Date, Hard Disk Type...	

Figure 3-1

Standard CMOS Features

Use this Menu for basic system configurations.

Advanced BIOS Features

Use this menu to set the Advanced Features available on your system.

Advanced Chipset Features

Use this menu to change the values in the chipset registers and optimize your system's performance.

Integrated Peripherals

Use this menu to specify your settings for integrated peripherals.

Power Management Setup

Use this menu to specify your settings for power management.

PnP/PCI configurations

This entry appears if your system supports PnP/PCI.

PC Health Status

This entry shows your PC health status.

Frequency/Voltage Control

Use this menu to specify your settings for frequency/voltage control.

Load Optimized Defaults

Use this menu to load the BIOS default values that are factory settings for optimal performances system operations.

Load Standard Defaults

Use this menu to load the BIOS default values for the minimal/stable performance system operation.

Set Supervisor/User Password

Use this menu to set User and Supervisor Passwords.

Save & Exit Setup

Save CMOS value changes to CMOS and exit setup.

Exit Without Saving

Abandon all CMOS value changes and exit setup.

3-4 Standard CMOS Features

The items in Standard CMOS Setup Menu are divided into several categories. Each category includes no, one or more than one setup items. Use the arrow keys to highlight the item and then use the <PgUp> or <PgDn> keys to select the value you want in each item.

CMOS Setup Utility - Copyright(C) 1984-2000 Award Software

Standard CMOS Features

Date (mm:dd:yy)	Wed, Oct, 18 2000	Item Help	
Time (hh:mm:ss)	17 : 40 : 36		
IDE Primary Master	Press Enter None	Menu Level > Change the day, moth, year and century	
IDE Primary Slave	Press Enter None		
IDE Secondary Master	Press Enter None		
IDE Secondary Slave	Press Enter None		
Drive A	1.44M, 3.25 in.		
Drive B	None		
Video	EGA/VGA		
Halt On	All Errors		
Base Memory	640K		
Extended Memory	64512K		
Total Memory	65536K		
Move Enter:Select Item +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help			
F5:Previous Values F6:Optimized Defaults F7:Standard Defaults			

Date

The date format is <day><month><date><year>.

Day Day of the week, from Sun to Sat, determined by BIOS. Read-only.

Month The month from Jan. through Dec.

Date The date from 1 to 31 can be keyed by numeric function keys.

Year The year depends on the year of the BIOS.

Time

The time format is <hour><minute><second>.

Primary Master/Primary Slave

Secondary Master/Secondary Slave

Press PgUp/<+> or PgDn/<-> to select Manual, None, Auto type. Note that the specifications of your drive must match with the drive table. The hard disk will not work properly if you enter improper information for this category. If your hard disk drive type is not matched or listed, you can use Manual to define your own drive type manually.

If you select Manual, related information is asked to be entered to the following items. Enter the information directly from the keyboard. This information should be provided in the documentation from your hard disk vendor or the system manufacturer.

If the controller of HDD interface is SCSI, the selection shall be "None".

If the controller of HDD interface is CD-ROM, the selection shall be “None”

Access Mode The settings are Auto Normal, Large, and LBA.
Cylinder number of cylinders
Head number of heads
Precomp write precomp
Landing Zone landing zone
Sector number of sectors

3-5 Advanced BIOS Features

CMOS Setup Utility - Copyright(C) 1984-2000 Award Software
 Advanced BIOS Features

Anti-Virus Protection	Disabled	Item Help
CPU Internal Cache	Enabled	
External Cache	Enabled	Menu Level > Allows you to choose the VIRUS warning feature for IDE Hard disk boot sector protection. If this function is enabled and someone attempt to write data into this area, BIOS will show a warning message on screen and alarm beep
CPU L2 Cache ECC Checking	Disabled	
Processor Number Feature	Enabled	
Quick Power On Self Test	Enabled	
First Boot Device	Floppy	
Second Boot Device	HDD-0	
Third Boot Device	LS120	
Fourth Boot Device	Enabled	
Swap Floppy Drive	Disabled	
Boot Up Floppy Seek	Enabled	
Boot Up NumLock Status	On	
Gate A20 Option	Fast	
Typematic Rate Setting	Disabled	
x Typematic Rate (Chars/Sec)	6	
x Typematic Delay (Msec)	250	
Security Option	Setup	
OS Select For DRAM > 64MB	Non-OS2	
Move Enter:Select Item +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults		

Anti-Virus Protection

Allow you to choose the VIRUS Warning feature for IDE Hard Disk boot sector protection. If this function is enabled and someone attempt to write data into this area, BIOS will show a warning message on screen and alarm beep.

Disabled (default) No warning message to appear when anything attempts to access the boot sector or hard disk partition table.

Enabled Activates automatically when the system boots up causing a warning message to appear when anything attempts to access the boot sector of hard disk partition table.

CPU Internal Cache

The default value is Enabled.

Enabled (default) Enable cache
Disabled Disable cache

Note: The internal cache is built in the processor.

External Cache

Choose Enabled or Disabled. This option enables the Level 2 cache memory.

CPU L2 Cache ECC Checking

Choose Enabled or Disabled. This option enables the Level 2 cache memory ECC (error check correction).

Processor Number Feature

This option is for Pentium® III processor. During Enabled, this will check the CPU Serial number. Disabled this option if you don't want the system to know the Serial number.

Quick Power On Self-Test

This category speeds up Power On Self Test (POST) after you power on the computer. If this is set to Enabled. BIOS will shorten or skip some check items during POST.

Enabled (default) Enable quick POST
Disabled Normal POST

First/Second/Third/Fourth Boot Device

The BIOS attempts to load the operating system from the devices in the sequence selected in these items. The settings are Floppy, LS/ZIP, HDD-0/HDD-1/HDD-3, SCSI, CDROM, LAN and Disabled.

Swap Floppy Drive

Switches the floppy disk drives between being designated as A and B. Default is Disabled.

Boot Up Floppy Seek

During POST, BIOS will determine if the floppy disk drive installed is 40 or 80 tracks. 360K type is 40 tracks while 760K, 1.2M and 1.44M are all 80 tracks.

Boot Up NumLock Status

The default value is On.

On (default) Keypad is numeric keys.

Off Keypad is arrow keys.

Gate A20 Option

Normal The A20 signal is controlled by keyboard controller or chipset hardware.

Fast (default) The A20 signal is controlled by port 92 or chipset specific method.

Typematic Rate Setting

Keystrokes repeat at a rate determined by the keyboard controller. When enabled, the typematic rate and typematic delay can be selected. The settings are: Enabled/Disabled.

Typematic Rate (Chars/Sec)

Sets the number of times a second to repeat a keystroke when you hold the key down. The settings are: 6, 8, 10, 12, 15, 20, 24, and 30.

Typematic Delay (Msec)

Sets the delay time after the key is held down before it begins to repeat the keystroke. The settings are 250, 500, 750, and 1000.

Security Option

This category allows you to limit access to the system and Setup, or just to Setup.

System The system will not boot and access to Setup will be denied if the correct password is not entered at the prompt.

Setup (default) The system will boot, but access to Setup will be denied if the correct password is not entered prompt.

OS Select For DRAM > 64MB

Allows OS2[®] to be used with >64MB or DRAM. Settings are Non-OS/2 (default) and OS2. Set to OS/2 if using more than 64MB and running OS/2[®].

Report No FDD For Win 95

Whether report no FDD for Win 95 or not. The settings are: Yes, No.

3-6 Advanced Chipset Features

The Advanced Chipset Features Setup option is used to change the values of the chipset registers. These registers control most of the system options in the computer.

CMOS Setup Utility - Copyright(C) 1984-2000 Award Software

Advanced Chipset Features

SDRAM CAS Latency Time	3	Item Help
SDRAM Cycle Time Tras/Trc	6/8	
SDRAM RAS-to-CAS Delay	3	Menu Level >
SDRAM RAS Precharge Time	3	
Special Buffer Strength	Enabled	
System BIOS Cacheable	Enabled	
Video BIOS Cacheable	Enabled	
Memory Hole at 15M-16M	Disabled	
CPU Latency Timer	Disabled	
Delayed Transaction	Disabled	
On-Chip Video Window Size	64MB	
Move Enter:Select Item +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults		

Note: Change these settings only if you are familiar with the chipset.

SDRAM CAS Latency Time

When synchronous DRAM is installed, the number of clock cycles of CAS latency depends on the DRAM timing. The settings are: 2 and 3.

SDRAM Cycle Time Tras/Trc

Select the number of SCLKs for an access cycle. The settings are: 5/7 and 6/8.

SDRAM RAS-to-CAS Delay

This field let's you insert a timing delay between the CAS and RAS strobe signals, used when DRAM is written to, read from, or refreshed. *Fast* gives faster performance; and *Slow* gives more stable performance. This field applies only when synchronous DRAM is installed in the system. The settings are: 2 and 3.

SDRAM RAS Precharge Time

If an insufficient number of cycles is allowed for the RAS to accumulate its charge before DRAM refresh, the refresh may be incomplete and the DRAM may fail to retain date. *Fast* gives faster performance; and *Slow* gives more stable performance. This field applies only when synchronous DRAM is installed in the system. The settings are: 2 and 3.

System BIOS Cacheable

Selecting Enabled allows caching of the system BIOS ROM at F0000h-FFFFFh, resulting in better system performance. However, if any program writes to this memory area, a system error may result. The settings are: Enabled and Disabled.

Video BIOS Cacheable

Select Enabled allows caching of the video BIOS, resulting in better system performance. However, if any program writes to this memory area, a system error may result. The settings are: Enabled and Disabled.

Memory Hole At 15M-16M

You can reserve this area of system memory for ISA adapter ROM. When this area is reserved, it cannot be cached. The user information of peripherals that need to use this area of system memory usually discusses their memory requirements. The settings are: Enabled and Disabled.

CPU Latency Timer

During Enabled, A deferrable CPU cycle will only be Deferred after it has been in a Snoop Stall for 31 clocks and another ADS# has arrived. During Disabled, A deferrable CPU cycle will be deferred immediately after the GMCH receives another ADS#.

Delayed Transaction

The chipset has an embedded 32-bit posted write buffer to support delay transactions cycles. Select Enabled to support compliance with PCI specification version 2.1. The settings are: Enabled and Disabled.

On-Chip Video Window Size

This option enabled/disabled the on-chip video windows size for VGA driver use. The settings are: enabled, Disabled.

3-7 Integrated Peripherals

CMOS Setup Utility - Copyright(C) 1984-2000 Award Software
Integrated Peripherals

> OnBoard IDE Function	Press Enter	Item Help
> OnBoard PCI DEVICE	Press Enter	
> Winbond SuperIO Device	Press Enter	Menu Level >
Init Display First	PCI Slot	
TV Output Mode	NTSC	
Move Enter:Select Item +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults		

OnBoard IDE Function

Please refer to section 3-7-1

OnBoard PCI Device

Please refer to section 3-7-2

Winbond SuperIO Device

Please refer to section 3-7-3

Init Display First

This item allows you to decide to activate whether PCI Slot or AGP VGA first. The settings are: PCI Slot, AGP Slot.

3-7-1 OnBoard IDE Function

CMOS Setup Utility - Copyright(C) 1984-2000 Award Software

OnBoard IDE Function

On-Chip Primary PCI IDE	Enabled	Item Help	
On-Chip Secondary PCI IDE	Enabled		
IDE Primary Master PIO	Auto	Menu Level >>	
IDE Primary Slave PIO	Auto		
IDE Secondary Master PIO	Auto		
IDE Secondary Slave PIO	Auto		
IDE Primary Master UDMA	Auto		
IDE Primary Slave UDMA	Auto		
IDE Secondary Master UDMA	Auto		
IDE Secondary Slave UDMA	Auto		
IDE HDD Block Mode	Enabled		
Move Enter:Select Item +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help			
F5:Previous Values F6:Optimized Defaults F7:Standard Defaults			

On-Chip IDE Primary/Secondary PCI IDE

The integrated peripheral controller contains an IDE interface with support for two IDE channels. Select *Enabled* to activate each channel separately. The settings are: Enabled and Disabled.

IDE Primary/Secondary Master/Slave PIO

The four IDE PIO (Programmed Input/Output) fields let you set a PIO mode (0-4) for each of the four IDE devices that the onboard IDE interface supports. Modes 0 through 4 provide successively increased performance. In Auto mode, the system automatically determines the best mode for each device. The settings are: Auto, Mode 0, Mode 1, Mode 2, Mode 3, Mode 4.

IDE Primary/Secondary Master/Slave UDMA

Ultra DMA/33 implementation is possible only if your IDE hard drive supports it and the operating environment includes a DMA driver (Windows 95 OSR2 or a third-party IDE bus master driver). If your hard drive and your system software both support Ultra DMA/33 and Ultra DMA/66, select Auto to enable BIOS support. The settings are: Auto, Disabled.

IDE HDD Block Mode

Block mode is also called block transfer, multiple commands, or multiple sector read/write. If your IDE hard drive supports block mode (most new drives do), select Enabled for automatic detection of the optimal number of block read/writes per sector the drive can support. The settings are: Enabled, Disabled.

3-7-2 OnBoard PCI DEVICE

CMOS Setup Utility - Copyright(C) 1984-2000 Award Software

OnBoard PCI DEVICE

USB Controller	Enabled	Item Help
USB Keyboard Support	Disabled	
OnBoard PCI LAN Device	Press Enter	Menu Level >>
** AC97 Codec is ALC100/200 **		
AC97 Audio	Auto	
Game Port Address	201	
Midi Port Address	330	
Midi Port IRQ	10	
AC97 Modem	Auto	
Move Enter:Select Item +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults		

USB Controller

Select *Enabled* if your system contains a Universal Serial Bus (USB) controller and you have USB peripherals. The settings are: Enabled, Disabled.

USB Keyboard Support

Select *Enabled* if your system contains a Universal Serial Bus (USB) controller and you have a USB keyboard. The settings are: Enabled, Disabled.

OnBoard PCI LAN Device

This item allows you to decide to enable/disable the OnBoard LAN controller to support LAN function. The settings are : Enabled, Disabled

AC97 Audio

This item allows you to decide to enable/disable the OnBoard AC 97' Codec chip to support Audio function. The settings are: Auto, Disabled.

Game Port Address/Midi Port Address

This will determine which Address the Game Port/Midi Port will use

AC97 Modem

This item allows you to decide to enable/disable the OnBoard AC 97' Codec chipset to support AC97 Modem. The settings are: Auto, Disabled.

3-7-3 Winbond SuperIO Device

CMOS Setup Utility - Copyright(C) 1984-2000 Award Software
Winbond SuperIO Device

POWER ON Function BUTTON ONLY KB Power ON Password Enter HOT Key Power ON Ctrl-F1 Onboard FDC Controller Enable Onboard Serial Port 1 3F8/IRQ4 Onboard Serial Port 2 2F8/IRQ3 UART Mode Select Normal RxD , TxD Active Hi,Lo IR Transmission Delay Enabled UR2 Duplex Mode Half Use IR Pins IR-Rx2Tx2 Onboard Parallel Port 378/IRQ7 Parallel Mode SPP EPP Mode Select EPP1.7 ECP Mode Use DMA 3 PWRON After PWR-Fail Off	Item Help Menu Level >>
Move Enter:Select Item +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults	

Onboard FDC Controller

Select Enabled if your system has a floppy disk controller (FDD) installed on the system board and you wish to use it. If you install add-on FDC or the system has no floppy drive, select Disabled in this field. The settings are: Enabled and Disabled.

Onboard Serial Port 1/Port 2

Select an address and corresponding interrupt for the first and the second serial ports. The settings are: 3F8/IRQ4, 2E8/IRQ3, 3E8/IRQ4, 2F8/IRQ3, Disabled, Auto.

UART Mode Select

This item allows you to determine which InfraRed(IR) function of the onboard I/O chip, this functions uses.

Onboard Parallel Port

There is a built-in parallel port on the on-board Super I/O chipset that Provides Standard, ECP, and EPP features. It has the following option:

Disabled

- (3BCH/IRQ7)/ Line Printer port 0
- (278H/IRQ5)/ Line Printer port 2
- (378H/IRQ7) Line Printer port 1

Onboard Parallel Mode

- SPP : Standard Parallel Port
- EPP : Enhanced Parallel Port
- ECP : Extended Capability Port
- SPP/EPP/ECP/ECP+EPP**

To operate the onboard parallel port as Standard Parallel Port only, choose “SPP.” To operate the onboard parallel port in the EPP modes simultaneously, choose “EPP.” By choosing “ECP”, the onboard parallel port will operate in ECP mode only. Choosing “ECP+EPP” will allow the onboard parallel port to support both the ECP and EPP modes simultaneously. The ECP mode has to use the DMA channel, so choose the onboard parallel port with the ECP feature. After selecting it, the following message will appear: “ECP Mode Use DMA” at this time, the user can choose between DMA channels 3 to 1. The onboard parallel port is EPP Spec. compliant, so after the user chooses the onboard parallel port with the EPP function, the following message will be displayed on the screen: “EPP Mode Select.” At this time either EPP 1.7 spec. or EPP 1.9 spec. can be chosen.

PWRON After PWR-Fail

This option will determine how the system will power on after a power failure

3-8 Power Management Setup

The Power Management Setup allows you to configure your system to most effectively save energy saving while operating in a manner consistent with your own style of computer use.

CMOS Setup Utility - Copyright(C) 1984-2000 Award Software

Power Management Setup

		Item Help
ACPI Function	Enabled	
Power Management	User Define	
Video off Method	V/H SYNC+Blank	
Video Off In Suspend	Yes	Menu Level >
Suspend Type	Stop Grant	
MODEM Use IRQ	3	
Suspend Mode	Disabled	
HDD Power Down	Disabled	
Soft-off by PWR-BTN	Instant-Off	
Wake-Up by PCI Card	Disabled	
Power On by Ring	Disabled	
CPU Thermal-Throttling	50.0%	
Resume by Alarm	Disabled	
x Date (of Month) Alarm	0	
x Time (hh:mm:ss) Alarm	0 : 0 : 0	
> Reload Timer Events	Press Enter	
Move Enter:Select Item +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults		

ACPI Function

This item allows you to Enabled/Disabled the Advanced Configuration and Power Management (ACPI). The settings are Enabled and Disabled.

Power Management

This category allows you to select the type (or degree) of power saving which is directly related to the following modes:

User Define(default) Allows you to set each mode individually. When not disabled, each of the ranges is from 1 min. to 1hr. except for HDD Power Down that ranges from 1 min. to 15 min. and disable.

Min Saving Minimum power management. Doze Mode 1H, Suspend Mode=1 hr., Power Down=15 min.

Max Saving Maximum power management. Doze Mode 1H, Suspend Mode=1 min., Power Down=1 min.

HDD Power Down

When enabled and after setting time of system inactivity, the hard disk drive will be powered down while all the other devices remain active.

The settings are: 1/2/3/4/5/6/7/8/9/10/11/12/13/14/15 Min and Disabled.

Suspend Mode

When enabled and after the set time of system inactivity, all devices except the CPU will be shut off.

The settings are: 1/2/4/8/12/20/30/40 Min, 1 Hour, and Disabled.

Video Off Option

This determines the manner in which the monitor is blanked. The choice are Suspend → off, All Modes → Off, and Always On.

Video Off Method

This determines the manner in which the monitor is blanked.

DPMS (default) Initial display power management signaling.

Blank Screen This option only writes blanks to the video buffer.

V/H SYNC+Blank This selection will cause the system to turn off the vertical and horizontal synchronization ports and write blanks to the video buffer.

Modem Use IRQ

This determines the IRQ in which the MODEM can use.

The settings are: 3, 4, 5, 7, 9, 10, 11, NA.

Soft-off by PWR-BTTN

Pressing the power button for more than 4 seconds forces the system to enter the Soft-Off state. The settings are: Delay 4 Sec, Instant-Off.

Wake Up by PCI card

This will enable the system to wake up to PCI Lan Card.

The settings are: Enabled and Disabled.

Power On by Ring

During Disabled, the system will ignore any incoming call from the modem. During Enabled, the system will boot up if there's an incoming call from the modem.

CPU Thermal-Throttling

Select the CPU THRM-Throttling rate. The settings are: 12.5%, 25.0%, 37.5%, 50.0%, 62.5%, 75.0%, 87.5%.

Resume by Alarm

This function is for setting date and time for your computer to boot up. During Disabled, you cannot use this function. During Enabled, choose the Date and Time Alarm:

Date(of month) Alarm

You can choose which month the system will boot up. Set to 0, to boot every day.

Time(hh:mm:ss) Alarm

You can choose what hour, minute and second the system will boot up.

Note: If you have change the setting, you must let the system boot up until it goes to the operating system, before this function will work.

Reload Timer Events

Please refer to section 3-8-1

3-8-1 Reload Timer Events

CMOS Setup Utility - Copyright(C) 1984-2000 Award Software
Reload Timer Events

Primary IDE 0	Disabled	Item Help
Primary IDE 1	Disabled	
Secondary IDE 0	Disabled	
Secondary IDE 1	Disabled	Menu Level >>
FDD,COM,LPT Port	Disabled	
PCI PIRQ[A-D]#	Disabled	
Move Enter:Select Item +/-/PU/PD=Value F10:Save ESC:Exit F1:General Help		
F5:Previous Values F6:Optimized Defaults F7:Standard Defaults		

Reload Timer Events

Reload Global Timer events are I/O events whose occurrence can prevent the system from entering a power saving mode or can awaken the system from such a mode. In effect, the system remains alert for anything that occurs to a device which is configured as *Enabled*, even when the system is in a power down mode.

Primary IDE 0

Primary IDE 1

Secondary IDE 0

Secondary IDE 1

FDD, COM, LPT Port

PCI PIRQ[A-D] #

3-9 PnP/PCI Configuration Setup

This section describes configuring the PCI bus system. PCI, or Personal Computer Interconnect, is a system which allows I/O devices to operate at speeds nearing the speed the CPU itself uses when communicating with its own special components. This section covers some very technical items and it is strongly recommended that only experienced users should make any changes to the default settings.

CMOS Setup Utility - Copyright(C) 1984-2000 Award Software

PnP/PCI Configurations

Reset Configuration Data	<u>Disabled</u>	Item Help
Resources Controlled By x IRQ Resources	Manual Press Enter	Menu Level >
PCI/VGA Palette Snoop	Disabled	Default is Disabled. Select Enabled to reset Extended System Configuration Data (ESCD) when you exit Setup if you have installed a new add-on and the system reconfiguration has caused such a serious conflict that the OS cannot boot
Move Enter:Select Item +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults		

Resource Controlled By

The Award Plug and Play BIOS has the capacity to automatically configure all of the boot and Plug and Play compatible devices. However, this capability means absolutely nothing unless you are using a Plug and Play operating system such as Windows®95/98. If you set this field to “manual” choose specific resources by going into each of the sub menu that follows this field (a sub menu is preceded by a “>”).

The settings are: Auto (ESCD), Manual.

IRQ Resources

When resources are controlled manually, assign each system interrupt a type, depending on the type of device using the interrupt.

PCI/VGA Palette Snoop

Leave this field at *Disabled*. The settings are Enabled, Disabled.

3-10 PC Health Status

This section shows the Status of you CPU, Fan, Warning for overall system status. This is only available if there is Hardware Monitor onboard.

CMOS Setup Utility - Copyright(C) 1984-2000 Award Software
PC Health Status

Show PC Health in Post	Enabled	Item Help
CPU Warning Temperatyre	Disabled	
Warning_Beep	Enabled	Menu Level >
Shutdown Temperature	Disabled	
Current System Temp.	25° C/77° F	
Current CPU Temperature	49° C/120° F	
Current FAN1 Speed.	4172 RPM	
Current FAN2 Speed.	4358 RPM	
Current FAN3 Speed.	4041 RPM	
Vcore	2.0 V	
Vtt(V)	1.55 V	
Vcc3.3	3.36 V	
+5V	4.94 V	
+12V	11.97 V	
-12V	-12.11 V	
-5V	- 4.94 V	
VBAT(V)	3.31 V	
5VSB(V)	5.34 V	
Move Enter:Select Item +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults		

Show PC Health in Post

During Enabled, it displays information list below. The choice is either Enabled or Disabled

Current CPU Temperature/Current System Temp/Current FAN1,FAN2,FAN3 Speed/Vcore/Vtt/Vcc3.3/+5V/+12V/-12V/-5V (V)

This will show the CPU/FAN/System voltage chart and FAN Speed.

Shutdown Temperature

This option is for setting the Shutdown temperature level for the processor. When the processor reaches the temperature you set, this will shutdown the system.

3-11 Frequency/Voltage Control

This section is for setting CPU Frequency Control.

CMOS Setup Utility - Copyright(C) 1984-2000 Award Software

Frequency/Voltage Control

Cyrix III Clock Ratio	Default	Item Help
Auto Detect DIMM/PCI Clk	Enabled	
Spread Spectrum	Disabled	
CPU Host/SDRAM Clock	Default	Menu Level >
CPU Clock Ratio	X 3	
Move Enter:Select Item +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F6:Optimized Defaults F7:Standard Defaults		

Auto Detect DIMM/PCI Clk

This item allows you to enable/disable auto detect DIMM/PCI Clock.

The settings are: Enabled, Disabled.

Spread Spectrum

This item allows you to set the Spread Spectrum.

CPU/SDRAM Clock

This item allows you to select the CPU/SDRAM Clock, refer to Page 13, 14, 15.

CPU Clock Ratio

This item allows you to select the CPU ratio.

3-12 Load Standard/Optimized Defaults

Load Standard Defaults

When you press <Enter> on this item, you get confirmation dialog box with a message similar to:

Load Standard Defaults (Y/N)? N

Pressing <Y> loads the BIOS default values for the most stable, minimal-performance system operations.

Load Optimized Defaults

When you press <Enter> on this item, you get a confirmation dialog box with a message similar to:

Load Optimized Defaults (Y/N)? N

Pressing <Y> loads the default values that are factory settings for optimal performance system operations.

3-13 Set Supervisor/User Password

You can set either supervisor or user password, or both of them. The differences are:

Supervisor password: Can enter and change the options of the setup menus.

User password: Can only enter but do not have the right to change the options of the setup menus. When you select this function, the following message will appear at the center of the screen to assist you in creating a password.

ENTER PASSWORD:

Type the password, up to eight characters in length, and press <Enter>. The password typed now will clear any previously entered password from CMOS memory. You will be asked to confirm the password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a password.

To disable a password, just press <Enter> when you are prompted to enter the password. A message will confirm that the password will be disabled. Once the password is disabled, the system will boot and you can enter Setup freely.

PASSWORD DISABLED.

When a password has been enabled, you will be prompted to enter it every time you try to enter Setup. This prevents an unauthorized person from changing any part of your system configuration.

Additionally, when a password is enabled, you can also require the BIOS to request a password every time your system is rebooted. This would prevent unauthorized use of your computer.

You determine when the password is required within the BIOS Features Setup Menu and its Security option. If the Security option is set to “System”, the password will be required both at boot and at entry to Setup. If set to “Setup”, prompting only occurs when trying to enter Setup.

Chapter 4

DRIVER & FREE PROGRAM INSTALLATION

Check your package and there is A MAGIC INSTALL CD included. This CD consists of all DRIVERS you need and some free application programs and utility programs. In addition, this CD also include an auto detect software which can tell you which hardware is installed, and which DRIVERS needed so that your system can function properly. We call this auto detect software MAGIC INSTALL.

MAGIC INSTALL supports WINDOWS 95/98/98SE/NT4.0/2000

Insert CD into your CD-ROM drive and the MAGIC INSTALL Menu should appear as below. If the menu does not appear, double-click MY COMPUTER / double-click CD-ROM drive or click START / click RUN / type X:\SETUP.EXE (assuming X is your CD-ROM drive).



From MAGIC INSTALL MENU you may make 9 selections:

- | | |
|--------------|---|
| 1. INF | install INTEL 810E chipset system driver |
| 2. IDE | install ULTRA ATA33 or ULTRA ATA 66 driver |
| 3. VGA | install on-board VGA driver |
| 4. PC-HEALTH | install PC-Health Monitor III software for hardware monitoring device |
| 5. SOUND | install AC97 sound driver and the program for editing/playback |
| 6. LAN | install Realtek RTL8139C 10/100M Fast Ethernet Lan Driver |
| 7. PC-CILLIN | install PC-CILLIN98 anti-virus program |
| 8. BROWSE CD | to browse the contents of the CD |
| 9. EXIT | to exit from MAGIC INSTALL menu |

Each selection is illustrated as below:

4-1 INF install INTEL 810E chipset system driver

After you have completed the installation of your operation system (WINDOWS 95/98/ 98SE). You will find an UNKNOWN DEVICE in the device manager (START/SETTING/CONTROL PANEL/SYSTEM/DEVICE MANAGER). You have to install INF driver as shown below:



1. Click INF in the MAGIC INSTALL MENU
2. Click NEXT when Chipset Software Install Utility appears



3. This chart shows motherboards supported by the driver click NEXT
4. Select if you want computer re-started click Finish


NOTE: MAGIC INSTALL will auto detect file path X:\INTEL810\INF\INFINST.EXE

This driver supports WINDOWS 95/98/98SE/2000 (NT4.0 do not require)


4-2 IDE install ULTRA ATA33 or ULTRA ATA 66 driver




1. Click IDE when MAGIC INSTALL MENU appears



2. Click NEXT when INTEL Ultra ATA Storage Wizard appears



3. This is to announce the Copy Right click NEXT



4. Click NEXT or BROWSE to change the path you want the driver stored



5. Select if you want to re-start your computer and click Finish



6. You may choose to remove the driver or you may remove it at ADD/REMOVE PROGRAMS

NOTE: MAGIC INSTALL will auto detect file path X:\INTEL810\Ide\SETUP.EXE


This driver supports WINDOWS 95/98/98SE/NT4.0/2000

4-3 VGA install on-board VGA driver

A. For WINDOWS 95/98/98SE/NT4.0



1. Click VGA when MAGIC INSTALL MENU appears
2. Click when INTEL 81X Family Chipset Graphics Driver Software appears



3. Click NEXT, this is to announce Copy Right
4. Select if you want to re-start computer and click Finish


NOTE: The path of the file
for WIN95 is X:\INTEL810\VGA\WIN95\SETUP.EXE
for WIN98 and WIN98SE is X:\INTEL810\VGA\WIN9X\SETUP.EXE
for NT4.0 is X:\INTEL810\VGA\NT40\SETUP.EXE

B. For WINDOWS 2000

Auto detects function for Windows 2000 is not provided, please load the VGA driver as follow:



1. When WINDOWS 2000 appears, Double click MY COMPUTER/CONTROL PANEL/SYSTEM/HARDWARE/ DEVICE MANAGER




2. Click OTHER DEVICE/VIDEO CONTROLLER (VGA COMPATIBLE)




3. Click DRIVER/UPDATE DRIVER





4. Click Next when update driver wizard appears. Then choose DISPLAY A LIST OF THE KNOWN DRIVERS FOR THIS DEVICE SO THAT I CAN CHOOSE A SPECIFIC DRIVER. Then click NEXT



5. Choose DISPLAY ADAPTERS from HARDWARE TYPE then click NEXT




6. Choose HAVE DISK from DEVICE DRIVER



7. When INSTALL FROM DISK appears, type X:\INTEL810\VIDEO\WIN2000, then click NEXT
8. Choose INTEL® 82810E GRAPHICS CONTROLLER from DRIVER LIST, then click NEXT. After Installation click NEXT, click FINISH and then Re-start the computer

4-4 PC-HEALTH installs PC HEALTH MONITOR IIII software for hardware monitoring device



1. Click PC-HEALTH when MAGIC INSTALL MENU appears
2. Click OK when PC HEALTH MONITOR IIII Setup appears



3. Click the Button to start installation
4. Click OK after setup complete

**NOTE: MAGIC INSTALL will auto detect file path X:\INTEL810\HEALTH\SETUP.EXE
This driver supports WINDOWS 95/98/98SE**

4-5 AC97 sound driver and the program Install for editing/playback




1. Click SOUND when MAGIC INSTALL MENU appears




2. Then auto detect operation system language edition, click OK, start to install DRIVER



3. When ask Remove old device driver, Click OK, Click GO



4. Click Finish and Restart Windows



5. Restart Windows will auto detect Avance AC97 Driver for 82801AA Controller Intel® 82801AA controller

NOTE: MAGIC INSTALL will auto detect file path:
X:\CODEC\ALC200\WIN95\SETUP.EXE (for WINDOWS 95)
X:\CODEC\ALC200\WIN98\SETUP.EXE (for WINDOWS 98/98SE)
X:\CODEC\ALC200\WINNT\SETUP.EXE (for WINDOWS NT4.0)
X:\CODEC\ALC200\WIN2000\SETUP.EXE (for WINDOWS 2000)


4-6 LAN (RTL 8139C) Install 10/100M PCI Fast Ethernet Driver

The path of the file:
for WINDOWS 95OSR2 is X:\RTL8139C\W95OSR2
for WINDOWS 98/98SE is X:\RTL8139C\WIN98
for WINDOWS 98ME is X:\RTL8139C\WIN98ME
for WINDOWS NT4.0 is X:\RTL8139C\WINNT4
for WINDOWS 2000 is X:\RTL8139C\WIN2000


WINDOWS 95/98/98SE Setup



1. Click LAN when Magic Install Menu appears
2. Lan Driver start Copy file



3. Driver install Finish, Click YES, restart the computer
4. After restart computer, Window can find Realtek RTL8139C PCI Fast Ethernet NIC



5. Select the best driver for your device, Select NEXT, Add New Hardware Wizard Find NETRTS5.INF Select NEXT
6. After restart computer you can check in control Panel\System Device Manager\ Network adapters to make sure Lan card Driver setup completely

4-7 PC-CILLIN install PC-CILLIN98 anti-virus program



1. Click PC-CILLIN when MAGIC INSTALL MENU Appears
2. Click NEXT when PC-CILIN 98 OEM SETUP APPEARS. Then click YES when the announcement of copywrite appears. Software is starting to detect HD for virus



3. Click NEXT or choose BROWSE to change the path For the file to be stored
4. Start to install the software, choose YES or NO when asked if you want PC-CILLIN To be added in ACTIVE CHANNEL or in Your internet browser



5. If you want to make a rescue disc, insert a 1.44 MB disc
6. Choose if you want to re-start and click FINISH

4-8 HOW TO UTILIZE ALSRACK EDITING & PLAYBACK UTILITY



1. Click START/PROGRAMS/AVANCE MEDIA PLAYER/ALSRACK. Then ALSRACK appears
2. This utility it can play from CD the effect just like HI-FI stereo system, also it can play *.WAN, *.MID format file




3. This is a sound environment simulator offering massive simulation including environment of opera pub stadium
 KARAOK playing having high low KEY tuning. Also BASS high low eight tune tuning and TREBLE high low eight tune tuning.

PS: After altering the options, there will be changes on the sound effect, user has to

reset all the option in order to have the original sound effects.

4-9 HOW TO UTILIZE PC-HEALTH



1. Click Program → PC HEALTH MONITOR III the PC HEALTH MONITOR III utility will appears, You can remove the Utility in Control Panel → Add/Remove Program icon
2. After executing PC HEALTH MONITOR III it supports system voltage, Fan speed and CPU/SYSTEM Temperature. Because this is a On-time Monitoring program therefore the value will change after it detected, if the value is over default setting the system will have warning picture and beeps

4-10 HOW TO DISABLE ON-BOARD SOUND

Enter BIOS SETUP choose INTEGRATE PERIPHERALS choose ON-CHIP DEVICE FUNCTION choose AC97 AUDIO Disable on-board sound function by press PAGE DOWN KEY to Disable

4-11 HOW TO UPDATE BIOS

STEP 1. Prepare a boot disc. (you may make one by click START click RUN type SYS A: click OK)

STEP 2. Copy utility program to your boot disc. You may copy from DRIVER CD X:\FLASH\AWDFLASH.EXE or download from our web site.

STEP 3. Copy latest BIOS for 613DF from our web site to your boot disc.

STEP 4. Insert your boot disc into A:,

start the computer, type "Awdflash A:\613DFxxx.BIN/SN/PY/CC/R"

613DFxxx.BIN is the file name of latest BIOS it can be 613DFA03.BIN or 613DFB02.BIN

SN means don't save existing BIOS data

PY means renew existing BIOS data

CC means clear existing CMOS data

R means restart computer

STEP 5. Push ENTER and the BIOS will be updated, computer will be restarted automatically.