
SECTION 4.

BIOS/SOFTWARE UTILITY

4-1 Flash Utility MAXFLASH.EXE

This section tells you a step-by-step procedure on how to use the flash utility, "maxflash.exe", upgrade your mainboard BIOS.

To upgrade your motherboard BIOS, please follow the following:

1. For Win95 system, press F8 before Win95 boot-up, and select "Safe mode command prompt only".
For Non-Win95 system, boot-up the system into DOS prompt with a bootable floppy disk.
!!!DO NOT load any memory manager like EMM386.EXE, QEMM386.EXE under config.sys.!!!
2. Run **A:>maxflash biosfile.bin**
3. After loading the new BIOS code, the utility will prompt you to save original BIOS code into your HDD or floppy. Please press "Y" to store it as "BIOS.OLD".
4. After the old BIOS has been successfully saved, press "Y" to replace BIOS.
5. After the flashing process, reboot the system by turn off the power.
!!! DO NOT TURN OFF THE POWER DURING THE FLASHING PROCESS. !!!
6. Press "DEL" key to enter BIOS setup during POST. Reload the "BIOS SETUP DEFAULT" and reconfigure other items as your previous set
7. Then save and exit.

IV.BIOS/SOFTWARE UTILITY

4-2 BIOS Flash/Upgrade Protection

This mainboard supports BIOS Flash/Upgrade protection which allows you protect your system BIOS being flashed by flash utility. We suggest you use this feature with Password Setting in BIOS to prevent your BIOS being flashed by flash utility.

To active the BIOS Flash/Upgrade protection, follow the steps below:

1. When the system boot up at POST (Power On Self- Test), press key to enter BIOS Setup Utility.
2. Set the "Flash/Upgrade BIOS" item in the "Integrated Peripherals" to Disabled.
3. Save the changes and exit Setup Utility.

, are so new, Win95 did not support them on Aug. of 1995


4-3 Remove Question Marks "?" in Win95 Device Manager

Since some of Intel 440BX/LX/EX latest technologies, like

which is the moment Win'95 formal released.

To solve this problem, please use the Maxtium Win95 patch utility – Mpatch.exe. You can find this utility under the directory \UTILITY in the bundled CD title.

After running the utility, you will see below screen. Select both



IV.BIOS/SOFTWARE UTILITY

4-4 Install Bus Master IDE (Ultra DMA/33) Driver

The Bus Master IDE (Ultra DMA/33) driver is available in the bundled CD title. You may run setup.exe directly to install the driver.

After installation, you will see following devices under Win95 Device Manager:

--- **Hard Disk Controllers**

Intel 82371AB PCI Bus Master IDE Controller

Primary Bus Master IDE Controller

Secondary Bus Master IDE Controller