

MagicLX/MagicEX

Pentium II[®] Mainboard

User's Manual

Model	: MagicLX/MagicEX
Manual version	: English, version 1.0
Release Date	: August 29, 1998

Copyright

Copyright © 1998 by this company. All rights reserved.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, electronic, mechanical, magnetic, optical, manual or otherwise, without the prior written consent of the copyright holders.

User' s Notice

The contents of this publication are subject to change. This company reserves the right to alter the contents of this publication at any time and without notice. The contents of this publication may contains inaccuracies or typographical errors and is supplied for informational use only.

Intel and Pentium are registered trademarks of Intel Corporation.

OS/2 and IBM are registered trademarks of International Business Machines.

Windows and MS-DOS are registered trademarks of Microsoft Corporation.

AWARD is a registered trademark of Award Software Inc.

Other brand, corporate, and product names may or may not be registered trademarks or copyright of their respective companies.

FCC & DOC Compliance

Federal Communications Commission Statement

This device complies with FCC Rules Part 15. Operation is subject to the following two conditions:

- ✧ This device may not cause harmful interference, and
- ✧ This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the manufacturer

communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ✧ Re-orient or relocate the receiving antenna.
- ✧ Increase the separation between the equipment and the receiver.
- ✧ Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- ✧ Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- ✧ Consult the dealer or an experienced radio/TV technician for help.

<p>Warning! The use of shielded cables for the connection of the monitor to the graphics card is required to assure compliance with FCC regulations Changes or modifications to this authority to operate this equipment.</p>

CONTENTS

SECTION 1: PRODUCT INFORMATION

1-1	Manual Features.....	1-1
1-2	Package Check List	1-1
1-3	Mainboard Specifications.....	1-2
1-4	Mainboard Layout	1-5

SECTION 2: HARDWARE INSTALLATION

2-1	Jumper Settings.....	2-1
2-1.1	CMOS Clear Setting	2-1
2-1.2	CPU Type & CPU Clock Setting	2-2
2-2	Connectors	2-3
2-2.1	Panel Connector	2-3
2-2.2	ATX Power Connector	2-4
2-2.3	AT Power Connector	2-4
2-2.4	Fan Connectors	2-5
2-2.5	PS/2 Mouse Connector	2-5
2-2.6	Keyboard Connector	2-6
2-2.7	USB Device Connector	2-6
2-2.8	Serial Device(COM1/COM2) Connector	2-7
2-2.9	Printer Connector	2-7

2-2.10	Floppy Drive Connector	2-8
2-2.11	IDE Hard Disk and CD-ROM Connector.	2-8
2-2.12	IrDA Connector	2-9
2-2.13	Audio Connector	2-10
2-2.14	Wake On LAN Connector	2-11

2-3 System Memory Installation2-11

2-3.1	Type	2-11
2-3.2	Speed	2-11
2-3.3	Buffered and Non-buffered	2-12
2-3.4	2-clock and 4-clock	2-12
2-3.5	Parity and Non-parity	2-13
2-3.6	Suggested SDRAM combination	2-13

SECTION 3: CMOS SETUP UTILITY

3-1	BIOS Setup Main Menu.....	3-1
3-2	Standard CMOS Setup.....	3-2
3-3	BIOS Features Setup	3-5
3-4	Chipset Features Setup	3-10
3-5	Power Management Setup.....	3-14
3-6	PNP/PCI Configuration	3-20
3-7	Load Setup Defaults	3-24
3-8	Load Turbo Defaults.....	3-25
3-9	Integrated Peripherals	3-26
3-10	Password Setting.....	3-31

3-11	IDE HDD Auto Detection	3-32
3-12	Save & Exit Setup.....	3-32
3-13	Exit with Saving	3-32

SECTION 4: BIOS/SOFTWARE UTILITY

4-1	Flash Utility Maxflash.exe.....	4-1
4-2	BIOS Flash/Upgrade Protection	4-2

SECTION 5: Audio Driver & Utility Installation

5-1	Windows 95/98 Driver&Utility Installation	5-1
5-2	Windows NT Driver Installation.....	5-5
5-3	DOS/Windows 3.1 Driver Installation	5-6
5-4	OS/2 Driver Installation.....	5-6