



JX30WB VL/ISA

SYSTEM BOARD

MANUAL

Specification Subject to Change Without Notice

Copyright 1994, Micronics Computers, Inc.

All Rights Reserved

Printed in USA

MICRONICS
JX30WB VL/ISA
SYSTEM BOARD
MANUAL

**Document Number: 06-00192-01, Rev 1B
August 1994
232 E. Warren Ave., Fremont, CA 94539-7085**

Copyright Notices

Micronics Computers, Inc.

The information contained in the JX30WB VL/ISA system board manual has been carefully checked and is believed to be accurate. Micronics assumes no responsibility for any inaccuracies that may be contained in this document.

Micronics makes no commitments to update or to keep the information in this manual at a current level when changes are made to the product.

Micronics reserves the right to make improvements to this document and/or product at any time and without notice.

No part of this document may be photocopied, reproduced, translated, or reduced to any medium or machine form without prior, written consent from Micronics.

COPYRIGHT (C) 1994, Micronics Computers, Inc.
232 E. Warren Ave., Fremont, California 94539-7085

Portions of the Manual

Portions of this manual were copied (with permission) from Phoenix Technologies, Ltd. Copyright 1994. All rights reserved.

Trademarks

IBM is a registered trademark of International Business Machines.
Microsoft, Microsoft Word, Windows are registered trademarks of Microsoft Corporation.
Intel and PCI are registered trademarks of Intel Corporation.
UNIX is a registered trademark of AT&T Corporation.
Lotus 1-2-3 is a registered trademark of Lotus Development Corp.

Table of Contents

Copyright Notices	ii
Micronics Computers, Inc.	ii
Portions of the Manual	ii
Trademarks	ii
Chapter 1: Introduction	1-1
Features	1-2
Software Compatibility	1-3
Chapter 2: Setting Up the JX30WB	2-1
Precautions	2-1
Static Electricity	2-1
Office Environment	2-1
JX30WB Components	2-2
Jumper Settings	2-3
Chapter 3: Installing Add-On Peripherals and System Memory ...	3-1
Installing a VL-Bus Card	3-1
Cache Memory	3-2
System Memory	3-3
Installing the SIMMs	3-3
Removing the SIMMs	3-4
Memory Configuration	3-4
SIMM-Types Supported	3-5
Installing an Enhanced CPU	3-5
Installing Cache Memory	3-6
128K of Level 2 Cache	3-7
Write-Through	3-7
Write-Back	3-7
256K of Level 2 Cache	3-8
Write-Through	3-8
Write-Back	3-8
512K of Level 2 Cache	3-9
Write-Through	3-9
Write-Back	3-9

Table of Contents (Cont'd)

Chapter 3 (Cont'd)

1MB of Level 2 Cache	3-10
Write-Through	3-10
Write-Back	3-10

Chapter 4: Installing and Configuring the JX30WB 4-1

Installation	4-1
Tools Required	4-1
Equipment Required	4-2
Configuration	4-2
Initial Boot Up	4-3
Setup	4-3
Running The Setup Procedure	4-4
Setting the CMOS Main Screen	4-6
System Time and Date	4-6
Diskette A or B	4-6
Hard Disk 1, 2, 3, or 4	4-6
Base Memory and Extended Memory	4-6
Video Card	4-7
System Speed	4-7
CPU Type	4-7
Cache State	4-7
External Cache Mode	4-8
Setting the CMOS Extended Screen	4-8
System BIOS	4-8
Video BIOS	4-8
On-Board Floppy	4-9
Primary IDE	4-9
Master Speed	4-9
Slave Speed	4-9
Secondary IDE	4-10
Serial Port 1 (Com 1)	4-10
Serial Port 2 (Com 2)	4-10
Parallel Port (LPT)	4-10
Parallel Port Mode	4-11
Standby Break Event IRQ	4-11

Table of Contents (Cont'd)

Energy Saving Timer	4-11
Chapter 4 (Cont'd)	
Non-Cacheable Area	4-12
Keyboard	4-12
System Password	4-13
Setup Password	4-13
Re-Configuring Your Computer	4-14
Appendix A: Post and Boot Error Messages	A-1
Appendix B: Beep Codes	B-1
Appendix C: Hard Disk Types	C-1
Appendix D: Specifications	D-1
Battery Disposal	D-3
Environmental Specifications	D-3
Temperature Range	D-3
Relative Humidity (Non-Condensing)	D-3
Glossary	G-1
Limited Warranty	W-1

List of Figures

Figure 2-1. JX30WB Rev. 1B System Board	2-2
Figure 3-1. Inserting a VESA Local Bus Card	3-2
Figure 3-2. Installing the SIMM	3-3
Figure 3-3. Installing 128K of Level 2 Cache	3-7
Figure 3-4. Installing 256K of Level 2 Cache	3-8
Figure 3-5. Installing 512K of Level 2 Cache	3-9
Figure 3-6. Installing 1MB of Level 2 Cache	3-10
Figure 4-1. Power-Up Screen	4-3
Figure 4-2. CMOS Main Screen	4-4
Figure 4-3. CMOS Extended Screen	4-5
Figure 4-4. Exit Pop-up Screen	4-14

Table of Contents (Cont'd)

List of Tables

Table 2-1. BIOS Operation Selection	2-3
Table 2-2. Video Monitor Display Selection	2-3
Table 2-3. Printer Port Configuration Selection	2-4
Table 2-4. CMOS Reset Selection	2-4
Table 2-5. SMI Configuration Selection	2-5
Table 2-6. Local Bus IDE Selection	2-5
Table 2-7. CPU Clock Selection	2-5
Table 2-8. Cache Size Selection	2-6
Table 2-9. CPU Type Selection (Jumpers W11-W21)	2-7
Table 2-10. CPU Type Selection (Jumpers W22-W28)	2-8
Table 2-11. Reserved Jumpers	2-9
Table 2-12. Peripheral and Case Connections	2-10
Table 3-1. DRAM Memory Configuration	3-4
Table A-1. POST Messages	A-1
Table B-1. Beep Codes	B-2
Table C-1. Hard Disk Types	C-1