# Origin<sup>™</sup> 2000, Silicon Graphics<sup>®</sup> Onyx2<sup>®</sup>, and SGI<sup>™</sup> 2000 Series Standard 19-Inch Rackmount Kit Installation Guide

Document Number 007-3603-003

#### **CONTRIBUTORS**

Written by Bruce Miles and Tom Dye
Illustrated by Dan Young and Kelly Begley
Production by Glen Traefald
Engineering contributions by Ed Freige Bruce Carrett David Io

Engineering contributions by Ed Freige, Bruce Garrett, David Johnson, and James Sarauer

Cover design by Sarah Bolles, Sarah Bolles Design, and Dany Galgani, SGI Technical Publications

# © 1998, 2000, Silicon Graphics, Inc.— All Rights Reserved

The contents of this document may not be copied or duplicated in any form, in whole or in part, without the prior written permission of Silicon Graphics, Inc.

## LIMITED AND RESTRICTED RIGHTS LEGEND

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in the Rights in Data clauses at FAR 52.227-14 and/or in similar or successor clauses in the FAR, or in the DOD, DOE, or NASA FAR Supplements. Unpublished rights reserved under the Copyright Laws of the United States. Contractor/manufacturer is Silicon Graphics, Inc., 1600 Amphitheatre Pkwy., Mountain View, CA 94043-1351.

The contents of this document may not be copied or duplicated in any manner, in whole or in part, without the prior written permission of Silicon Graphics, Inc.

Silicon Graphics and Onyx2 are registered trademarks and Origin and SGI are trademarks of Silicon Graphics, Inc.

## **FCC Warning**

This equipment has been tested and found compliant with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

## Attention

This product requires the use of external shielded cables in order to maintain compliance pursuant to Part 15 of the FCC Rules.

International Special Committee on Radio Interference (CISPR)

This equipment has been tested to and is in compliance with the Class A limits per CISPR publication 22, Limits and Methods of Measurement of Radio Interference Characteristics of Information Technology Equipment; Germany's BZT Class A limits for Information Technology Equipment; and Japan's VCCI Class 1 limits.

## Canadian Department of Communications Statement

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications.

#### Attention

Cet appareil numérique n'émet pas de perturbations radioélectriques dépassant les normes applicables aux appareils numériques de Classe A préscrites dans le Règlement sur les interferences radioélectriques établi par le Ministère des Communications du Canada.

この装置は、第一種情報装置(商工業地域において使用されるべき情報装置)で商工業地域での電波障害防止を目的とした情報処理装置等電波障害自主規制協議会(VCCI)基準に適合しております。

従って、住宅地域またはその隣接した地域で使用すると、ラジオ、テレビジョン受信機等に受信障害を与えることがあります。

取扱説明書に従って正しい取り扱いをして下さい。

# Contents

# List of Figures vii About This Guide ix 1. Installing the Rackmount Kit 1 About the Rackmount Kit 1 Checking the Kit Contents 2 Understanding Safety Issues 4 Preparing the System 5 Powering Down the System 5 Removing the System Facade 5 Removing the System Tophat 7 Removing the System Side Panels 9 Removing the System Bottom Plenum and Pedestal Assembly 10 Installing the System 11

# List of Figures

Figure 1-1	Rackmount Kit 3
Figure 1-2	Removing the System Facade 6
Figure 1-3	Removing the System Tophat 8
Figure 1-4	Removing the System Side Panels 9
Figure 1-5	Removing the System Bottom Plenum and Pedestal Assembly 10
Figure 1-6	Connecting the Shelf Assembly to the Side Retma Rails 12
Figure 1-7	Connecting the Shelf Assembly to the Front and Rear Retma Rails 13
Figure 1-8	Attaching the Chassis Brackets 14
Figure 1-9	Attaching the Front Panel and Plenum Cover 16
Figure 1-10	Attaching the Rear Brackets 17

# About This Guide

This guide describes how to use the Rackmount Kit to install an Origin  $^{\rm TM}$  2000 system, a Silicon Graphics Onyx2 system, or an SGI 2000 series system into an Electronic Industry Association (EIA) standard 19-inch equipment rack. This information is written for SGI customers who are responsible for all installation procedures. This guide details the contents of the kit, safety issues, and installation.

# Installing the Rackmount Kit

This chapter describes how to convert an Origin 2000, Onyx2, or SGI 2000 series system to a rackmount configuration. It contains the following sections:

- "About the Rackmount Kit"
- "Checking the Kit Contents"
- "Understanding Safety Issues"
- "Preparing the System"
- "Installing the System"

# **About the Rackmount Kit**

The Origin 2000, Onyx2, and SGI 2000 Series Rackmount Kit provides quick and easy rackmount installation for Origin 2000, Onyx2, or SGI 2000 series systems. It contains all the hardware needed to install one deskside system in a half-size or full-size EIA standard 19-inch equipment rack.

**Note:** This kit is designed for installing SGI systems in single equipment racks only. It is not designed for connecting systems in multiple equipment racks. Any alterations made to the rackmount kit hardware will void the product's warranty. SGI is not responsible for any equipment damage due to alterations in the rackmount hardware.

Due to the various design configurations of third-party EIA standard 19-inch equipment racks, this rackmount kit does not fit every 19-inch third-party rack. When using a third-party rack, it is acceptable to use the support shelves provided by the rack manufacturer if they provide adequate air flow and are designed to support the maximum weight of an SGI system (190 pounds).

# **Checking the Kit Contents**

Before beginning the installation procedure, verify that all parts necessary for installation are present (see Figure 1-1). If any items are missing, contact SGI or your local service provider. The Rackmount Kit should contain all the following parts:

- Intake plenum\* (1)
- Exhaust plenum (1)
- Adjustable shelves (4)
- Extender shelves (4)
- Chassis brackets (2)
- Plenum brackets\* (2)
- Rear brackets (4)
- Shelf brackets\* (4)
- Plenum front cover\* (1)
- Front panel (1 Onyx2, Origin 2000, or SGI 2000 series)
- Front panel screws (8)
- 10-32 x 3/8 flathead mounting screws (22)
- 8-32 x 3/8 panhead mounting screws (8)
- 10-32 x 3/8 panhead mounting screws (80)
- 10-32 kep nuts (80)
- Flat washers (72)
- \* Optional equipment. Shelf brackets are required only for systems without side mounting retma rails. The top intake plenum is not required with an SGI system that is mounted in the top of a rack and if the top of the rack meets the following conditions:
- Adequately ventilated
- Perforated
- Allows air to be drawn vertically into the rack system




Figure 1-1 Rackmount Kit

# **Understanding Safety Issues**

The Origin 2000, Onyx2, and SGI 2000 series products have been certified and licensed by international safety agencies for use in the following ways:

- As stand-alone units
- For installation in SGI model CMN-A017 rack systems

Although the hardware in this kit enables you to mount these systems in third-party EIA standard 19-inch equipment racks, installation in such racks may require submittal to an approved safety agency for their evaluation and certification/licensing of the new rack-system combination. Check with your local building inspector for requirements applicable to your location.

This kit is not designed for shock and vibration dampening. If operating an SGI system in a harsh environment subject to intense vibration, it is recommended that you configure the rack with appropriate mounting hardware to protect the integrity of the system components.

# **Preparing the System**

To prepare the Origin 2000, Onyx2, or SGI 2000 series system for installation, see Figures 1-2 through 1-5 and complete the following procedures.


# **Powering Down the System**

- 1. Shut down the system.
- 2. Disconnect all cables at the rear of the system, including the cables for power, networking, serial, router interconnect, grounding, and so on.

# Removing the System Facade

To remove the system facade (or front door), see Figure 1-2 and follow these steps:

- 1. Remove the screw that holds the facade in place.
- 2. Push down on top of the door frame to release the door and pull it out.



**Figure 1-2** Removing the System Facade

# **Removing the System Tophat**

To remove the system tophat, see Figure 1-3 and follow these steps:

- 1. Remove the system tophat by inserting a flathead screwdriver under one of the four tophat caps (panel 4).
- 2. Locate the securing latch towards the rear of the cap and push the latch forward (panel 5).
- 3. Lift up the cap (panel 6).
- 4. Repeat steps 1 through 3 for each of the caps.
- 5. Remove the four screws that hold the tophat to the system chassis (panel 7).
- 6. Remove the tophat (panel 8).





Figure 1-3 Removing the System Tophat

# **Removing the System Side Panels**

To remove the system side panels, see Figure 1-4 and follow these steps:

- 1. Remove the system tophat.
- 2. Pull out the AC cover.
- 3. Grasp the side panels by the bottom, pull up, and then lift out.




**Figure 1-4** Removing the System Side Panels

# Removing the System Bottom Plenum and Pedestal Assembly

To remove the system bottom plenum and pedestal assembly, see Figure 1-5 and follow these steps:

- 1. Remove the system tophat and side panels.
- 2. Remove the four screws that secure the pedestal assembly at the sides.
- 3. Lift the system chassis from the pedestal assembly.



**Figure 1-5** Removing the System Bottom Plenum and Pedestal Assembly

# Installing the System

To install a system chassis in an EIA standard 19-inch equipment rack and attach the Rackmount Kit hardware, see Figures 1-6 through 1-9 and follow these steps:

- 1. Select a location within the equipment rack where the system will be located. The system requires 18 rack units (U) with the intake plenum and 15U without the intake plenum. (One rack unit is equal to 1.75 inches.)
- 2. Connect the adjustable shelf to the extender shelf with the mounting screws (see Figure 1-6). You can adjust this hardware to accommodate various depths. The final shelf assembly length should be able to mount between the front and rear retma rails. (You can also use the shelving hardware supplied with the rack, if applicable.)

**Note:** Some equipment racks do not have the side retma rails required for side mounting the shelf assemblies as shown in Figure 1-6. In such cases, you must use the shelf brackets to mount the shelf assemblies to the front and rear retma rails, as shown in Figure 1-7. If both types of retma rails are available, side mounting is recommended.

- 3. Attach the left and right exhaust plenum shelf assemblies to the equipment rack front and rear retma rails with the mounting screws (see Figure 1-6 or Figure 1-7). The adjustable shelves should be facing toward the front of the rack. (This shelf assembly supports the bottom of the exhaust plenum. Be sure to position the shelf assembly in the exact area where the exhaust plenum will be located.)
- 4. Attach the left and right system chassis shelf assemblies to the equipment rack with the mounting screws (see Figure 1-6 or Figure 1-7). The adjustable shelves should be facing toward the front of the rack. (This shelf assembly supports the bottom of the system chassis and must be positioned 3U above the exhaust plenum shelf assembly.)




Figure 1-6 Connecting the Shelf Assembly to the Side Retma Rails




Figure 1-7 Connecting the Shelf Assembly to the Front and Rear Retma Rails

5. Position the exhaust plenum on the lower shelf assemblies and slide the plenum three-fourths of the way into the equipment rack (see Figure 1-8). Be sure the open side of the plenum is facing up and the open end is facing the rear.

**Note:** To ensure proper installation, remove the rectangular bracket from the plenum before sliding it into the equipment rack. Discard the bracket after installation.

- 6. Position the system chassis on top of the upper shelf assemblies and slide the system three-fourths of the way into the equipment rack (see Figure 1-8).
- 7. Loosely attach the left and right chassis brackets to the system chassis and the exhaust plenum with the flathead and panhead mounting screws (see Figure 1-8).
- 8. Slide the system chassis and the exhaust plenum completely into the system until the chassis brackets rest against the retma rails.





Figure 1-8 Attaching the Chassis Brackets

9. An intake plenum is required to ensure proper air flow when installing an SGI system in the bottom of an equipment rack or the top of an equipment rack with a covered top. If needed, position the intake plenum on top of the system chassis and attach the plenum brackets to the plenum with the mounting screws (see Figure 1-8). Be sure the open side of the plenum is facing down and the open end is facing the front.

**Note:** To ensure proper installation, remove the rectangular bracket from the plenum before sliding it into the equipment rack. Discard the bracket after installation.

10. Position the front panel mounting holes over the chassis bracket mounting holes and attach the panel and chassis brackets to the equipment rack front retma rails with the mounting screws (see Figure 1-9).

**Note:** If an intake plenum is installed, attach the front plenum cover in the same manner as the front panel.



**Figure 1-9** Attaching the Front Panel and Plenum Cover

11. To ensure system stabilization, use the mounting screws to attach one end of the rear brackets to the lower, rear left side and right side of the system chassis (see Figure 1-10). Then attach the other end of the rear brackets to the left and right rear chassis shelf assemblies.




Figure 1-10 Attaching the Rear Brackets

- 12. To ensure exhaust plenum stabilization, use the mounting screws to attach one end of the rear brackets to the rear left and right side of the exhaust plenum. Then attach the other end of the rear brackets to the left and right rear exhaust plenum shelf assemblies.
- 13. The system chassis rackmount installation is now complete. Connect all cables at the rear of the system, including the cables for power, networking, serial, router interconnect, and grounding. Then power on the system.