



IZ TECHNICAL MEMO:

Revised RADAR I Motherboard Jumper Settings For 486 DX2-66 upgrade

Contact iZ Support: (800) 776-1356

Memo Date: November 15, 2000

CPU Installation Notes:

To modify original motherboard: GREEN-B (4GPV3) from 25-megahertz 486SX processor to 486DX2 66 megahertz you must do the following:

(As per page seven (7) in users manual)

CPU: 80486DX	JP2	JP3	JP4
	1-2 & 3-4	2-3	OPEN

JP2A	1-2	FOR INTEL CPU
-------------	------------	----------------------

TO SET SYSTEM FOR 33 or 66 MHZ PROCESSOR

(As per page eight (8) in users manual)

NOTE: JUMPER JP5 IS **WRONG** IN MANUAL!!!!

FOR 33 MHz FOR DX/SX –33 or DX2-66 SET AS FOLLOWS	
JP36	SHORT
JP37	2-3
JP38	1-2
JP5	*** 1-2 *** (WRONG IN MANUAL)
JP72	OPEN
JP33	2-4
ID3	OPEN

VESA BUS (VL-Bus Page 10) Wait State

ID2	OPEN 0 wait State
-----	-------------------

**** NOTE: A HEAT SINK ON THE 66 MHz CPU MOUNTED WITH A HIGH QUALITY THERMAL COMPOUND SUCH AS WAKEFIELD NON-SILICONE THERMAL COMPOUND PART NO. 126-2 IS HIGHLY RECOMMENDED.**