

Chapter 1

1

Introduction

How This Manual is Organized

This manual is divided into the following sections:

- | | | |
|------------------|---------------------|---|
| Chapter 1 | Introduction | : Manual information and checklist. |
| Chapter 2 | Features | : Information and Specifications concerning this mainboard. |
| Chapter 3 | Installation | : Instructions on setting up the board. |

Package Checklist

Please check that your package is complete . Should any item be damaged or missing , please contact your retailer immediately.

- ⌚ The 6A815E1/6A815EP1 mainboard.
- ⌚ 1 x IDE UDMA100 ribbon cable.
- ⌚ 1 x COM2 cable.
- ⌚ 1 x Floppy ribbon cable.
- ⌚ 6A815E1/815EP1 support software:
 - CD driver and utilites.
 - Intelinf (Intel(R) chipset software to system containing 815E chipset)
 - Easy Over Clock
 - (Realtek-AP (Selecting the CPU Frequency))
 - Uatadrv (Intel(R) ultra ATA storage setup)
 - Sound (on board sound driver)
- ⌚ This user's Manual