


Appendix II

Quick Connector and Jumper Reference



JP3: CPU cooling fan connector




JP20: Clear CMOS data

- 1~2 short : Normal (default)
- 2~3 short : Clear CMOS data


J4: PS/2 mouse connector




J13: Infrared connector



J14: Dual channel USB connector



J15 : Front panel connector set



Set the CPU type via BIOS :

CPU-type	CPU Power Voltage		System freq./Freq. ratio		
	IO Vcc	Core Vcc	MHz	Speed rate	
Intel	P54C-90	3.5	60	x1.5	
	P54C-120			x2	
	P54C-150			x2.5	
	P54C-100			x1.5	
	P54C-133		66	x2	
	P54C-166			x2.5	
	P54C-200			x3	
	Pentium w/MMX 166MHz			3.3	2.8
Pentium w/MMX 200MHz	x3				
Pentium w/MMX 233MHz	x3.5				
Cyrrix /IBM	6x86-PR133 ⁺ @110MHz	3.5	60	x2	
	6x86-PR150 ⁺ @120MHz				
	6x86-PR166 ⁺ @133MHz				
	6x86L-PR166 ⁺ @133MHz				
AMD	3.3	2.9	60	x1.5	
					K5-PR90
					K5-PR100
					K5-PR120 @90MHz
			66	x2	
					K5-PR133 @100MHz
					K5-PR150 @105MHz
					K5-PR166 @116.7MHz
K6/PR2-200	66	x3			



Memo