Appendix 1: Quick Jumper Setting Reference

JP1: Clear CMOS memory jumper


Function	Jumper Cap Position	JP1	1	
Normal Operation	Short pins 1-2		Ō	2
Clear CMOS Memory	Short pins 2-3	Default		3

JP2: Keyboard Power On jumper

Function	Jumper Cap Position	1 2 3
Disable keyboard power switch	Short pins 1-2	● ● ● JP2
Enable keyboard power switch	Short pins 2-3	Default

JP3: Mouse & Keyboard enable/disable jumper

Function	Jumper Cap Position				
	Pins 1-2	Pins 3-4	Pins 5-6	Pins 7-8	
Keyboard/Mouse Enable	Short	Short	Short	Short	
Keyboard/Mouse Disable	Open	Open	Open	Open	



PANEL1: Connectors for Case Switches and LEDs

Pins	Function			
1 to 3	Power indicator LED			
4 to 5	Sleep switch			
7 to 9	Suspend indicator LED			
10 to 11	Keyboard lock			
12 to 13	System reset switch			
15 to 18	System speaker connector			
20 to 21	Hard disk drive indicator LED			
22 to 23	Power On/Off switch			
	10 11 12 13 15 18 20+21- 22 23 0 0 0 0 0 0 0 0			
Power Sleep Suspend				

1 0 1 0 1	oleep	ouspena	110	110001	opeaker	1100	
LED	SW	LED	Lock	SW		LED	SW