

CPU Jumper Settings: JC1, JC2, JC3, JC4, JC5, RNA, RNC, RNI

Intel :

486SX/DX/DX2; DX4 ODP; P24S; P24D; P24T;

IntelDX4 -

(Double-Speed: A80486DX4-XX*,

Triple-Speed: A80486DX4-XX*)

	JC1	JC2	JC3	JC4	JC5	RNA	RNC	RNI
486SX								
486DX/DX2 P24S								
DX4 ODP P24D								
P24T								
DX4 (Double-Speed)								
DX4 (Triple-Speed)								

* When using this processor, please refer to page 2-11 for more information about jumper setting.

