

**AMD :****486DX2 -****(A80486DX2-XXV8T\*, A80486DX2-XXNV8T\*);****486DX4 -****(A80486DX4-100NV8T\*, A80486DX4-XXSV8B\*,****Am486DX4-100V8T\*);****AMD-X5\***

	JC1	JC2	JC3	JC4	JC5	RNA	RNC	RNI
486DX2								
Enhanced 486DX2								
486DX4								
Enhanced 486DX4								
AMD-X5								

\* When using this processor, please refer to page 2-11 for more information about jumper setting.

