












W83787F/787IF Controller: JW1, JW2, JW3, JW4, JI1, J1

W83787IF/877F	JW1	JW2
COM2		
Infrared		

ECP Mode	JW3	JW4
DMA 1 (Default)		
DMA 3		

Printer Port Direction	J11
OUTPUT	
Bidirection (Default)	

Programmable Flash EPROM Type	J1
Intel 28F001BX-T	
SST 29EE010	