

CONNECTOR	SIDE A - PINS AND PIN OUTS		SIDE B - PINS AND PIN OUTS	
	PIN	OUT	PIN	OUT
SL14 — Local Bus	01	DAT01	01	DAT00
	02	DAT03	02	DAT02
	03, 10, 17, 24, 35, 43, 51	Ground	03	DAT04
	04	DAT05	04	DAT06
	05	DAT07	05	DAT08
	06	DAT09	06, 14, 22, 29, 38, 49, 55	Ground
	07	DAT11	07	DAT10
	08	DAT13	08	DAT12
	09	DAT15	09, 20, 32, 57	VCC
	11	DAT17	10	DAT14
	12, 27, 40, 53	VCC	11	DAT16
	13	DAT19	12	DAT18
	14	DAT21	13	DAT20
	15	DAT23	15	DAT22
	16	DAT25	16	DAT24
	18	DAT27	17	DAT26
	19	DAT29	18	DAT28
	20	DAT31	19	DAT30
	21	ADR30	21	ADR31
	22	ADR28	23	ADR29
	23	ADR26	24	ADR27
	25	ADR24	25	ADR25
	26	ADR22	26	ADR23
	28	ADR20	27	ADR21
	29	ADR18	28	ADR19
	30	ADR16	30	ADR17
	31	ADR14	31	ADR15
	32	ADR12	33	ADR13
	33	ADR10	34	ADR11
	34	ADR08	35	ADR09
	36	ADR06	36	ADR07
	37	ADR04	37	ADR05
	38	WBACK#	39	ADR03
	39	BE0#	40	ADR02
	41	BE1#	41	NC
	42	BE2#	42	RESET#
	44	BE3#	43	D/C#
	45	ADS#	44	M/IO#
	48	LRDY#	45	W/R#
	49	LDEV1#	48	RDYRTN#
	50	LREQ#	50	IRQ9
	52	LGNT#	51	BRDY#
	54, 55, 56	ID2, 3, 4	52	BLAST#
	57	LKEN#	53, 54	ID0, 1
	58	LEADS#	56	LCLK1
			58	LBS16#

Table 2-6. Local Bus Connector Pin Assignment (Continued)