




**Cyrix 486DX/DX2****Cyrix 486DX-V/DX2-V**

\* A regulator board may be needed when using this CPU's. Please refer to page 2-8 for its installation.

**Cyrix 486SX****CPU Clock Jumper JK1-JK4**

	50 MHz DX50	40 MHz DX40 DX2-80	33.3 MHz (Default) SX33 DX2-50 DX4-100	25 MHz SX25 DX2-25 DX4-75
JK1	3 2 1	3 2 1	3 2 1	3 2 1
JK2	3 2 1	3 2 1	3 2 1	3 2 1
JK3	3 2 1	3 2 1	3 2 1	3 2 1
JK4	3 2 1	3 2 1	3 2 1	3 2 1