

Jumper Setting for CPU Clock

JC2	Clock Rate 1:2 (50 MHz/ 100 MHz) 2:3 (50 MHz/ 75 MHz; 60 MHz/ 90 MHz; 66 MHz/ 100 MHz) (Default)		
	50 MHz	60 MHz	66 MHz (Default)
JK1			
JK2			
JK3			

Jumper Setting for I/O

J1	Display Type <input type="checkbox"/> Mono/EGAVGA <input checked="" type="checkbox"/> CGA
JCP	Password Clear <input checked="" type="checkbox"/> Enabled <input type="checkbox"/> Disabled (Default)
J1	NS87332/87334 <input type="checkbox"/> IR serial port (for NS334) <input checked="" type="checkbox"/> COM Port (for NS332) (Default)

Jumper Setting for System

J15	CPU Voltage <input type="checkbox"/> Others <input checked="" type="checkbox"/> 3.3 Volts
J16	CPU Voltage <input type="checkbox"/> Others <input checked="" type="checkbox"/> 3.5 Volts (Default)
JC1	Internal Write-Back/Write-Through Cache <input checked="" type="checkbox"/> Write-Back (Default) <input type="checkbox"/> Write-Through
JP2	Hardware Reset <input checked="" type="checkbox"/> Enabled <input type="checkbox"/> Disabled (Default)