

Table of Contents

Chapter 1 Installation Procedures

Clear Password: CPS.....	2
Flash EPROM Type Selection: EP1, EP2	2
CPU External Clock (BUS) Frequency: CLK1, CLK2, CLK3.....	3
CPU Internal Freq. to Bus Clock Ratio: FREQ1, FREQ2, FREQ3.....	3

Chapter 2 BIOS Setup

Award BIOS Setup	5
CMOS Setup Utility.....	5
Standard CMOS Setup.....	6
Hard Disk Configurations	6
Software Turbo Speed.....	7
BIOS Features Setup.....	7
Chipset Features Setup.....	10
Power Management Setup.....	12
PNP/PCI Configuration Setup	16
Load BIOS Defaults.....	18
Load Setup Defaults.....	18
Integrated Peripherals	19
Supervisor/User Password	23
IDE HDD Auto Detection	23
Save and Exit Setup	24
Exit without Saving.....	24

This Page Intentionally Left Blank