

## ***Table of Contents***

### **Chapter 1 Installation Procedures**

Clear Password: CPW.....	2
Flash ROM Type Selection: EP1, EP2 .....	3
Power Supply Type Selection: PWR .....	4
CPU to SRAM Data Transacting Mode Selection: SRAM.....	4
CPU External Clock (BUS) Frequency: CLK1, CLK2, CLK3 .....	5
CPU Internal Freq. to Bus Clock Ratio: FREQ1, FREQ2, FREQ3 .....	5

### **Chapter 2 BIOS Setup**

CMOS Setup Utility .....	7
Standard CMOS Setup.....	8
Hard Disk Configurations.....	8
Software Turbo Speed .....	9
BIOS Features Setup.....	10
Chipset Features Setup .....	13
Power Management Setup.....	16
PNP/PCI Configuration Setup .....	20
Load BIOS Defaults.....	22
Load Setup Defaults.....	22
Integrated Peripherals.....	22
Supervisor/User Password.....	24
IDE HDD Auto Detection .....	27
Save and Exit Setup .....	28
Exit without Saving.....	28

**This Page Intentionally Left Blank**