

AGP Support Brace Installation Procedure

AGP Support Brace



1. Locate the AGP slot.



2. Insert the AGP support brace into the AGP slot hole.



3. Push to secure the AGP support brace.



Addendum

4. Check for a perfect fit.



5. Insert the AGP card into AGP slot.



6. Insert the AGP Support Brace Cap into the AGP Support Brace.



7. Push Downward to secure the AGP card.

