

# Software Installation

## 2. Software Installation

### 2.0 Please Select Model Name

Included in the Motherboard package you can find a CD-disk which contains the support drivers & utilities. Please insert this support CD-disk into your CD-ROM drive of PC, wait for the Autorun Screen then click "**PT-693A-A**" for into the drivers & utilities installation.

Step1



Step2



### 2.1 Install VIA 4 in 1 Drivers


Click "Install VIA 4 in 1 Drivers".

Please follow the step charts below for installation.

Step1



Step2



# Software Installation

---

## 2.2 Install Sound Driver (for onboard Audio only)

Click "Install Sound Driver"

Please follow the step charts below for intallation

Step1



Step2



## 2.3 Install Hardware Monitor Utility

Click "Install Hardware Monitor Utility"

Please follow the step charts below for intallation.

Step1



## 2.4 Install Adobe Acrobat Reader

Please follow the step charts below for intallation.

## Step2



Click "Other Driver Search" for other drivers & utilities demand.

The screenshot shows a Windows XP-style interface. The title bar reads "雷军博客 - PT-691AAA-A". The menu bar includes "檔案(F)", "編輯(E)", "格式(O)", "移至(M)", "我的最愛(A)", "工具(T)", and "說明(H)". The toolbar contains icons for Back, Forward, Up, Down, Copy, Paste, Delete, Print, Favorites, and Views. The address bar shows "網址(N) | Y:\PT-691AAA-A". The left pane shows a tree view with folders like (C:), (D:), Drivers(D), Data, and PT-691AAA-A selected. The right pane displays the contents of PT-691AAA-A, listing files such as backup, Device7, hda\_xwp4, HMDocDoc, HModDoc, iacdrv, Manual, SoundDev, Utility, Vga\_drv, Asd(Cch), Asd(Sesg), AutoRun, Cdico, Rbocal, and Setupplan.