

Software Installation

2.2 Install VGA Driver

Click "Install VGA Driver"

Please follow the step charts below for intallation.

Step1



Step2



2.3 Install Sound Driver (for onboard Audio only)

Click "Install Sound Driver"

Please follow the step charts below for intallation.

Step1



Step2



Software Installation

2.4 Install Hardware Monitor Utility

Click "Install Hardware Monitor Utility"

Please follow the step charts below for intallation.

Step1



2.5 Install Adobe Acrobat Reader

Click "Install Adobe Acrobat Reader"

Please follow the step charts below for intallation.

Step1



Step2



Software Installation

2.6 Other Driver Search

Click "Other Driver Search" for other drivers & utilities demand.

Step1

