

Chapter 4

DRIVER SETUP

1. Overview

The Cyrix®GXm™ and Cx5520™ on-chip VGA offers highly integrated 2D Graphic/Video accelerator. Its 2D performance produce compelling interactive multimedia. It is also designed for high-quality MPEG/video playback to users.

1.1 System Requirements

This section describes system requirements for the VGA Driver installation and Usage.

Computer	200MHz Cyrix®GXm™ processor or above
Monitor	VGA Support, minimum 640x480 resolution
Operating system	DOS® 5.0 or higher, Windows®95, Windows®NT 3.51 or 4.0
CD-ROM	Double Speed or Higher
Chipset	Cyrix®Cx5520™
VGA BIOS	Version 1.0 or Higher

2. Cyrix® MediaGX™ VGA/Audio/Joystick Driver Setup & Usage Procedures

Insert the MS-5176 CD into your CD-ROM drive. This CD will auto-run. This will display installation for VGA driver, Sound driver, and Joystick driver. Also included are Norton® Antivirus and Softcooler . Just click the button for automatic installation for the driver.

2.1 Windows® 95

2.1-1 Display Driver Installation Procedure:

- Step 1:** Insert the MS-5176 Cd-Title into the CD-ROM drive.
- Step 2:** Click “Device Drivers” item.
- Step 3:** Select **OK** to continue the setup.
- Step 4:** Setup Procedure will auto install Display, Audio, and Joystick Drivers.
- Step 5:** A setup successful dialog will appear when setup is complete. You can restart the system now.

2.1-2 Changing resolution, color depth, and refresh rate:

- Step 1:** Click **Start** menu and select **Control Panel** from **Settings** group.
- Step 2:** Select **Display** icon.
- Step 3:** Select **Settings**.
- Step 4:** Select Color Palette to change between 16 color, 256 color, or Hi color.
- Step 5:** Select desktop resolution from 640x480, 800x600, 1024x768 to 1280x1024.
- Step 6:** Select Refresh rate list box to change the screen refresh rate.
- Step 7:** Click OK or Apply.

2.1-3 Windows®95 Utility Installation:

- Step 1:** Insert the MS-5176 Cd-Title Disk into the CD-ROM drive.
- Step 2:** Select Norton® Anti-Virus or SoftCooler item.
- Step 3:** Setup procedure will automatically install the utility.
- Step 4:** A setup successful dialog will appear when setup is complete, user can choose to restart the system now or later.

2.2 Windows® NT 4.0

2.2-1 Display Driver Installation Procedure:

- Step 1:** Click **Start** menu and select **Control Panel** from **Settings** group.
- Step 2:** Select **Display** icon.
- Step 3:** Select **Settings** on the Display Properties.
- Step 4:** Select **Display Type**.
- Step 5:** Select **Change** from the **Adapter Type** Area.
- Step 6:** Select **Have Disk** of Change Display.
- Step 7:** Insert the **MS-5176 CD-Title Disk** into CD-ROM Drive.
- Step 8:** When the Install from Disk dialog box appears, look for your CD-ROM drive :**\Cyrux MediaGX\NT4.0**.
- Step 9:** When the **Change Display** dialog box appears, click **OK**.
- Step 10:** When the Third-party Drivers dialog box appears, click **Yes**.
A message will appear stating that the drivers were successfully installed. Click **OK**. You must now restart your system.

2.2-2 Changing resolution, color depth, and refresh rate:

- Step 1:** Click **Start** menu and select **Control Panel** from **Settings** group.
- Step 2:** Select **Display** icon.
- Step 3:** Select **Settings**.
- Step 4:** Select Color Palette to change between 16 color, 256 color, 32768 colors, and 65536 colors.
- Step 5:** To select desktop resolution size, go to the Desktop area and use the slide bar to change resolution from 640x480, 800x600, 1024x768, to 1280x1024.
- Step 6:** Select **Test** to test the resolution. If the display test screen is good, then select **Yes** when the Testing Mode dialog box appears. If the display test screen is bad, then select **No**. Windows®NT will give you an error message.
- Step 7:** Click **OK**. If you selected **Yes**, Windows®NT 4.0 will change the mode without restarting.
-