

## HANDLING PRECAUTIONS

→ Static electricity may cause damage to the integrated circuits on the mainboard. Before handling any mainboard outside of its protective packaging, ensure that there is no static electric charge in your body. Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

Observe any or all of these basic precautions when handling the mainboard or other computer components:

- Wear a static wrist strap which fits around your wrist and is connected to a natural earth ground.
  - Touch a grounded or anti-static surface or a metal fixture such as a water pipe.
  - Avoid contact with the components on add-on cards, boards and modules and with the "gold finger" connectors plugged into the expansion slot. It is best to handle system components by their mounting bracket.
- Above methods either prevent static build-up or cause it to be discharged properly.

### TRADEMARKS <sup>TM</sup>

**IBM** registered trademark of International Business Machines Corp.  
**Intel/ Pentium** registered trademark of Intel Corp.

*All other trademarks mentioned in this manual are registered property of the respective owners.*

### COPYRIGHT©

*This manual may not, in whole or in part, be photocopied, reproduced, transcribed, translated, or transmitted in whatsoever form without the written consent of the manufacturer, except for copies retained by the purchaser for personal archival purposes.*

PA-2000

## Table of Contents

<b>Chapter 1 Overview</b>	
Specifications	1-1
Mainboard Layout	1-3
System Block Diagram	1-4
<b>Chapter 2 Mainboard Settings</b>	
Jumpers	2-1
Jumper Setting for CPU Clock	2-2
Jumper Setting for I/O	2-2
Jumper Setting for System	2-3
<b>Chapter 3 System Memory</b>	
Memory Locations	3-1
Installing DRAM	3-2
SIMM Banks	3-2
DRAM Configuration	3-2
Installation Instructions	3-4
Cache Memory	3-5
Installing Cache Memory	3-5
Cache SRAM Specifications and Settings	3-6
Using Various Voltage SRAM	3-6
256KB Cache SRAM	3-7
512KB Cache SRAM	3-7
1MB Cache SRAM	3-8
<b>Chapter 4 Award BIOS Setup</b>	
CMOS Setup Utility	4-1

PA-2000