FRONT

PICTURE 1

September 1991

This package contains an  $\it IBM$  TouchSelect Option and Utilities Diskette,  $\it IBM$  TouchSelect Starter Diskette, and instructions for running the diagnostics.

IBM and PS/2 are trademarks of the International Business Machines Corporation.

| Copyright International Business Machines Corporation 1991. All rights reserved

Note to U.S. Government users-Documentation related to Restricted rights-Use, duplication, or disclosure is subject to restrictions set forth in GSA ADP Schedule Contract with IBM Corp.

Part Number 92F2221

Form Number SA33-7001-00

## Diagnostics

- 1. Turn off the display and system unit.
- 2. Ensure that power is available at the electrical outlet (if there is no power, consult your supervisor) and continue with the next step.
- 3. Ensure that the display is conveniently positioned on a firm surface.
- 4. Ensure the TouchSelect device cable is plugged into the mouse port.
- 5. If you have a IBM Industrial Computer 7541 or a PS/2 8545 or higher model number go to Step 9, otherwise continue below.
- 6. Insert the IBM TouchSelect Starter Diskette in drive A.
- 7. Turn on the system unit and display.
- 8. When the main menu appears press  ${\tt Enter}$ ,  ${\tt 0}$ ,  ${\tt Enter}$ , continue with Step 13.
- 9. Insert the IBM TouchSelect Option and Utilities diskette in drive A.
- 10. Turn on the system unit and display.
- 11. When the main menu appears press and hold  ${\tt Ctrl}$  and press  ${\tt A}$  for advanced diagnostics.
- 12. Select System Checkout, select Y, select Run tests one time, select Touch device, select Run all tests.
- 13. Follow the instructions on the screen.
- 14. Were you able to to complete testing without errors?
  - Yes The TouchSelect device appears to be working correctly. If you are still having problems and have gone through the Problem Determination procedure, contact your IBM Service Representative.
  - No If the diagnostics indicates a mouse problem, replace it with a known good mouse (if available) and rerun diagnostics. If problem remains replace your TouchSelect device.

## Parts List

12 inch TouchSelect w/logo	04G1594
12 inch TouchSelect w/o logo	10G3769
14 inch TouchSelect w/logo	10G6819
19 inch TouchSelect w/logo	84F7170
19 inch TouchSelect w/o logo	84F7171