

Chapter 3

There are motherboard drivers and utilities included in ACORP Bonus CD disc. You don't need to install all of them in order to boot your system. But after you finish the hardware installation, you have to install your operation system first (such as windows 98) before you can install any drivers or utilities. Please refer to your operation system installation guide.

Note: Please follow recommended procedure after install Windows ME and Windows 98.

3.1 Auto-run Menu

You can use the auto-run menu of Bonus CD disc. Choose the utility or driver and select model name.




3.2 Installing SiS AGP Driver


SiS 630 chipset integrated a 2D/3D graphics acceleration. This item install the SiS AGP for Microsoft Windows 95/98SE/ME/NT4.0/2000/XP.




(1)
Click
"SiS AGP Driver" Item.



(2)
For Win 9x/2000
/NT/XP System.
Select your system.




(3)
Click "Next".



(4)
Click "Next".



(5)
Click "Next".




(6)
Click "Next".

3.3 Installing Aduio Driver

This item install the SiS Audio for Microsoft Windows 95/98SE/ME/NT4.0/2000/XP. This motherboard comes with an SiS 7018 AC'97 CODEC.



(1)
Click
"Audio Driver" Item.



(2)
Click "Next".



(3)
Click "Next".

3.4 Installing Onboard LAN Driver

When your mainboard comes with the SiS 900 PCI 10/100Mb Fast Ethernet Adapter, you must install the SiS® LAN driver to support the LAN function. In some operating systems like Windows 9X, Windows 2000, Windows NT the provided CD will auto-run when you insert the CD disk into the CD-ROM drive.



(1)
Click
"Onboard LAN Driver"
Item.



(2)
Click "Next".