

## Contents

---

<b>Chapter 1: Introduction .....</b>	<b>1</b>
Welcome .....	1
About the Manual .....	2
Checklist.....	3
Standard Items-----	3
Recommendations .....	3
Features .....	4
 <b>Chapter 2: Installation .....</b>	 <b>7</b>
Quick Installation Table.....	7
Quick Jumper Setting Reference .....	8
Before You Begin .....	9
Static Electricity -----	9
Choosing a Case -----	10
How to Set Jumpers -----	10
Preparing the Mainboard.....	12
Mainboard Guide -----	12
*LD1 -----	13
I/O Ports Side View -----	14
Check the Jumper Settings -----	15
Install the Mainboard in the Case.....	18
Connecting Power and Case Switches & Indicators --	20
Install Other Hardware .....	21
Install the Processor -----	21
Installing a Socket-7 Processor -----	22
Install the Memory Modules-----	24
Install a Hard Disk Drive and CD-ROM -----	25
Installing a Floppy Diskette Drive -----	28
Using the Expansion Slots-----	29
Add-in Card Options -----	31
Install Options and Extension Brackets -----	32
Make the External Connections .....	35
External Connector Color Coding-----	36
 <b>Chapter 3: Setup .....</b>	 <b>37</b>
About the Setup Utility .....	37
Starting the Setup Utility -----	37
How to Flash a New BIOS-----	39
Standard CMOS Setup Option .....	40

BIOS Features Setup Option.....	42
Chipset Features Setup Option .....	45
Power Management Setup Option .....	48
PNP/PCI Configuration Option .....	52
Load BIOS Defaults Option .....	53
Load Optimum Settings Option .....	53
Integrated Peripherals Option .....	54
Password Settings.....	56
IDE HDD Auto Detection Option .....	57
Save And Exit Setup Option.....	57
Exit Without Saving Option .....	57
 <b>Chapter 4: Software .....</b>	<b>58</b>
About the Software .....	58
Folders for this Mainboard .....	58
Running the Support CD-ROM.....	60
Utility Folder Installation Notes .....	60
CMI8X38 Folder Installation Notes.....	61
Audio Software-----	61
Modem Driver and Software-----	62
Peripheral Folder Installation Notes .....	62
SiS_IDE Folder Installation Notes .....	63
Mainboard (P5SS-ML) Installation Notes .....	64
 <b>Appendix 1: Quick Jumper Setting Reference .....</b>	<b>65</b>
 <b>Appendix 2: CPU Settings Table .....</b>	<b>67</b>
 <b>Appendix 3: Glossary .....</b>	<b>69</b>