

5 Install Sound Blaster Drivers and Applications

The set of Installation Diskettes is as follows:

- ① **Driver for Windows 3.1**
- ① **Accessories for Windows 3.1**
- ① **Driver for Windows 95**
- ① **Applications for Windows 95**
- ① **Driver for Windows NT**

Driver and Accessories for Windows 3.1

Installation Instructions

1. Insert Driver for Windows 3.1 diskette in a drive, say drive A.
2. Type **A:\install /n** at DOS prompt.
3. Click O.K. button.

Driver and Applications for Windows 95

Installation Instructions

1. Insert Driver for Windows 95 diskette in a drive, say drive A.
2. Click “Start” button on task bar.
3. Choose “Run” item on popup menu.
4. Type **A:\setup** in open command line.
5. Click O.K. button.

Driver for Windows NT

Installation Instructions

1. Start Control Panel.

2. Activate Drivers application in the Control Panel.
3. Choose the “Add...” button.
4. Select “Unlisted or Updated Driver” from the “List of Drivers” list box and choose “O.K.”
5. Insert the diskette of Driver for Windows NT in a drive, ex. drive A, and type **A:\nt351** in command line, then click “O.K.” button.
6. Choose the “O.K.” button on the popup dialog box with “Creative Tech. Sound Blaster 16” entry in a list box.



If users already have Sound Blaster 16 drivers installed, you have to uninstall them before installing the new drivers. For instructions on uninstalling the drivers, turn to the next section.

7. Choose the appropriate IRQ, DMA, and I/O address values on the displayed “Sound Blaster 16 Configuration” dialog box and press “O.K.” button to complete installation.
8. Restart the system after the drivers are installed.

Uninstalling the Drivers

1. Start Control Panel and activate the drivers.
2. Choose “Creative Tech. Sound Blaster 16” from “Installed Drivers” and select the “Remove” button.
3. Answer “Yes” on the prompted confirmation dialog box.