


# Quick Jumper Setting Reference


## JP3: Enable/Disable Onboard Audio

Function	Jumper Cap
Enable Audio	Short Pins 1-2
Disable Audio	Short pins 2-3



## JP6: Clear CMOS Memory

Function	Jumper Cap
Clear CMOS	Short Pins 1-2
Normal Operation	Short pins 2-3



## PANEL1: Connectors for Case Switches and LEDs

Function	Pins
Power LED	+1, +2, 3
Sleep Switch	4, 5
Suspend LED	+6, +7, 8
Reset Switch	9, 10
Key Lock	11, 12
Speaker	+13, 14, 15, 16
Hard Disk LED	+17, 18
Power Switch	+19, 20

