

Contents

Chapter 1: Introduction	1
Welcome	1
About the Manual	2
Checklist.....	3
Standard Items	3
Recommendations	3
Features	4
 Chapter 2: Installation.....	 7
Quick Installation Table.....	7
Quick Jumper Setting Reference.....	8
Before You Begin.....	10
Static Electricity	10
Choosing a Case	10
How to Set Jumpers	11
Preparing the Mainboard.....	12
Mainboard Guide	12
I/O Ports Side View.....	14
Check the Jumper Settings	15
Install the Mainboard in the Case.....	17
Connecting Power, Chassis Fan, and Panel	19
Install Other Hardware	21
Install the Processor.....	21
Installing a Slot1 Processor	23
Installing a Socket-370 Processor.....	25
Install the Memory Modules	27
Install a Hard Disk Drive and CD-ROM.....	28
Installing a Floppy Diskette Drive	31
Using the Expansion Slots.....	32
Add-in Card Options.....	34
Install Options and Extension Brackets.....	35
Make the External Connections	38
 Chapter 3: Setup	 39
About the Setup Utility	39
Starting the Setup Utility.....	39
How to Flash a New BIOS	41
Standard CMOS Setup Option.....	42
BIOS & CPU Features Setup Option.....	43
Chipset Features Option.....	46

Power Management Setup Option	48
PNP/PCI Configuration Option.....	51
Load BIOS Defaults Option	52
Load Setup Defaults Option	52
Integrated Peripherals Option	53
Password Setting	55
IDE HDD Auto Detection Option	56
Save And Exit Setup Option	56
Exit Without Saving Option.....	56

Chapter 4: Software	57
About the Software	57
Folders for this Mainboard.....	57
Running the Support CD-ROM	59
Utility Folder Installation Notes	59
CMI8X38 Folder Installation Notes.....	60
Audio Software	60
Modem Driver and Software	61
Peripheral Folder Installation Notes	61
SiS_IDE Folder Installation Notes	61
SiS620_VGA Folder Installation Notes	62
Mainboard (P6SET-ML) Installation Notes.....	62

Appendix 1: Quick Jumper Setting Reference	63
---	-----------