

Addendum

Warning

The LAN function had been built-in this version of P6STP-FL (with 630E chipset). Normally, the network adaptor has its one MAC address to identify the IP of its hardware. The MAC address, also called LAN ID address, of the network adapter may lose if you Flash a new BIOS after clearing the CMOS memory, or you clear the CMOS right after flashing the BIOS.

In the situation that the MAC address is loss, please use the following steps to input your MAC address.

1. Go to the BIOS setup screen.
2. Select "Integrated Peripherals Options".
3. Select "SiS900 MAC Address Input". (Please refer to page 50)
4. Locate "MAC Address" labeled "EA" on the parallel port.
5. Enter the "MAC Address"
6. Press F10 to save the change.
7. Reboot your system.

Please notice that in the process of Flashing the BIOS, be sure to add parameter "/cd". Otherwise, the MAC address will lose.

Driver: \AWD763.exe xxxx.bin/cd [Enter]