

4. Carefully apply enough pressure to partially seat the chip into the socket.

Ensure that all pins are properly aligned with the connectors and that there are no bent pins. If there are any bent pins, remove the chip, straighten the pin and repeat the process.

5. Press the chip completely into the socket so that the pins are properly seated.

## **Cache SRAM Specifications and Settings**

---

### **128K Cache SRAM**

M1	32Kx8
M2	32Kx8
M3	32Kx8
M4	32Kx8
M5	32Kx8 (TAG)

### **256K Cache SRAM**

M1	64Kx8
M2	64Kx8
M3	64Kx8
M4	64Kx8
M5	32Kx8 (TAG)