

Mainboard Settings

SIDE A: PINS AND PIN-OUTS		SIDE B: PINS AND PIN-OUTS	
01	DAT01	01	DAT00
02	DAT03	02	DAT02
03, 10, 17, 24, 35, 43, 51	Ground	03	DAT04
04	DAT05	04	DAT06
05	DAT07	05	DAT08
06	DAT09	06, 14, 22, 29, 38, 49, 55	GROUND
07	DAT11	07	DAT10
08	DAT13	08	DAT12
09	DAT15	09, 20, 32, 57	VCC
11	DAT17	10	DAT14
12, 27, 40, 53	VCC	11	DAT16
13	DAT19	12	DAT18
14	DAT21	13	DAT20
15	DAT23	15	DAT22
16	DAT25	16	DAT24
18	DAT27	17	DAT26
19	DAT29	18	DAT28
20	DAT31	19	DAT30
21	ADR30	21	ADR31
22	ADR28	23	ADR29
23	ADR26	24	ADR27
25	ADR24	25	ADR25
26	ADR22	26	ADR23
28	ADR20	27	ADR21
29	ADR18	28	ADR19
30	ADR16	30	ADR17
31	ADR14	31	ADR15
32	ADR12	33	ADR13
33	ADR10	34	ADR11
34	ADR08	35	ADR09
36	ADR06	36	ADR07
37	ADR04	37	ADR05
38	WBACKE#	39	ADR03
39	BE0#	40	ADR02
41	BE1#	41	NC
42	BE2#	42	RESET#
44	BE3#	43	DIC#
45	ADS#	44	MIC#
48	LRDY#	45	WR#
49	LDEV#	48	RDYRTN#
50	LREQ#	50	IRQ8
52	LGNT#	51	BRDY#
54, 55, 56	ID2, 3, 4	52	BLAST#
57	LKEN#	53, 54	ID0, 1
58	LEADS#	56	LCLK0
		58	LBS16#

Table 2-7. SL15 Local Bus Connector Pin Assignment

486-PVT

Mainboard Settings

SIDE A: PINS AND PIN-OUTS		SIDE B: PINS AND PIN-OUTS	
01	DAT01	01	DAT00
02	DAT03	02	DAT02
03, 10, 17, 24, 35, 43, 51	Ground	03	DAT04
04	DAT05	04	DAT06
05	DAT07	05	DAT08
06	DAT09	06, 14, 22, 29, 38, 49, 55	Ground
07	DAT11	07	DAT10
08	DAT13	08	DAT12
09	DAT15	09, 20, 32, 57	VCC
11	DAT17	10	DAT14
12, 27, 40, 53	VCC	11	DAT16
13	DAT19	12	DAT18
14	DAT21	13	DAT20
15	DAT23	15	DAT22
16	DAT25	16	DAT24
18	DAT27	17	DAT26
19	DAT29	18	DAT28
20	DAT31	19	DAT30
21	ADR30	21	ADR31
22	ADR28	23	ADR29
23	ADR26	24	ADR27
25	ADR24	25	ADR25
26	ADR22	26	ADR23
28	ADR20	27	ADR21
29	ADR18	28	ADR19
30	ADR16	30	ADR17
31	ADR14	31	ADR15
32	ADR12	33	ADR13
33	ADR10	34	ADR11
34	ADR08	35	ADR09
36	ADR06	36	ADR07
37	ADR04	37	ADR05
38	WBACKE#	39	ADR03
39	BE0#	40	ADR02
41	BE1#	41	NC
42	BE2#	42	RESET#
44	BE3#	43	DIC#
45	ADS#	44	MIC#
48	LRDY#	45	WR#
49	LDEV#	48	RDYRTN#
50	LREQ#	50	IRQ8
52	LGNT#	51	BRDY#
54, 55, 56	ID2, 3, 4	52	BLAST#
57	LKEN#	53, 54	ID0, 1
58	LEADS#	56	LCLK0
		58	LBS16#

Table 2-8. SL16 Local Bus Connector Pin Assignment

486-PVT